

TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT, AND

SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS

(INCLUDING DEPOT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOL

KETTLE, HEATING, BITUMINOUS, GEN

TRAILER MOUNTED, 165 GALLON CAPA

(GENERAL STEEL TANK MODEL 190

FSN 3895-351-2354

This copy is a reprint which includes current
pages from Change 1.

**Organizational, Direct Support And
General Support Maintenance
Repair Parts And Special Tools List
(Including Depot Maintenance Repair
Parts and Special Tools)**

**KETTLE, HEATING, BITUMINOUS; GED;
TRAILER MOUNTED; 165 GALLON CAPACITY
(GENERAL STEEL TANK MODEL 1901)
FSN 3895-351-2354**

Current as of 9 November 1973

3895-339-24P, 3 October 1972, is changed as follows:

1, paragraph 6. Change lines 5 and 6 to read, "To Commander, US Army Troop
and, ATTN: AMSTS-MPP".

3, column 2, group 03, line 1. Change FSN 5305-964-0119 to read, "5305-855-0968".

4, column 2, group 04, line 5. Add FSN "4730-196-1557" for 5½ inch pipe nipple.

5, column 1, group 6, line 13. Change code XBOZZ to read, "PAOZZ". Column 2, add
"391-3771".

7, column 1, line 3. Change code XBOZZ to read, "PAOZZ"; column 2, add FSN "3895-351-2354".
Column 1, line 9, change code XBOZZ to read, "PAOZZ"; column 2, add FSN "3895-351-2354".

8, column 2, group 07, line 5. Add FSN "5330-472-7847".

10, column 2, line 10. Change FSN "5935-925-6494" to read, "5935-925-6495". Column 2, add
"Contact".

12, column 2, group 12, line 9. Change FSN 4030-869-1529 to read, "4030-869-1520".

17, column 2, line 20. Add FSN "3895-451-4812". Column 1, line 21, change code
"PAFZZ"; column 2, add FSN "5306-225-8498"; and column 3, change "Screw,
Bolt, Machine".

30, line 3. Add FSN 3893-431-4813 .

Page 22, column 1, line 15. Change code XBOZZ to read, "PAOZZ". Column 2, 277-8289".

Page 25, column 1, line 23. Change code XBOZZ to read, "PAOZZ". Column 2, 167-7775". Column 2, line 25, change FSN 5935-925-6494 to read, "5935-925-6495"; Terminal to read, "Contact".

Page 26, column 1, line 13. Change Code XBOZZ to read, "PAOZZ". Column 2, 841-6798".

Page 28, column 2, group 12, line 9. Change FSN 4030-869-1529 to read, "4030-869-1529".

Page 45. Federal Stock Number 5305-225-3839, add Fig. No. 11, item No. 4. FS add Fig. No. 8, item No. 19.

Page 47. Reference No. 419009, fig. No. 3, item No. 10, change Mfg. code 38740

Page 48. Change Reference No. 60288-01A to read, "602088-01A".

By Order of the Secretary of the Army:

Official:

CREIGHTON
General, Unit
Chief of Staff

VERNE L. BOWERS,
Major General, United States Army,
The Adjutant General.

Distribution:

To be distributed in accordance with DA Form 12-25B, (qty rqr block No. 4 al maintenance requirements for Heaters, Bituminous.

ORGANIZATIONAL, DIRECT SUPPORT, AND
GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS)
KETTLE, HEATING, BITUMINOUS, GED,
TRAILER MOUNTED, 165 GALLON CAPACITY
(GENERAL STEEL TANK MODEL 1901)

FSN 3895-351-2354

Current as of 11 October 1972

SECTION	I.	INTRODUCTION
	II.	PREScribed LOAD ALLOWANCE LIST (Not applicable)
	III.	ORGANIZATIONAL MAINTENANCE REPAIR PARTS LIST
Group	01.	Engine, engine mount, fuel tank coupling, shaft and collar
	02.	Gear reducer, clutch and shifter lever, pump and pump bracket
		Gear reducer
		Clutch and shifter lever
		Asphalt pump and pump bracket
Group	03.	Pump and gearbox case and mounting plate
	04.	Valves, fittings, hose assemblies, and thermometer
	05.	Hand spray attachment and flexible hose
	06.	Fuel tank, pressure gage, air pump, valves, lines, and fittings
	07.	Temperature control assembly
	08.	Burner assembly
	09.	Intervehicular cable, lights, reflectors and wiring harness
	10.	Spring, hanger assemblies, spring and axle clamp, and U-bolt
	11.	Wheel, axle, and hub assemblies
	12.	Tank, lid, support jacks, and frame
SECTION	IV.	ORGANIZATIONAL MAINTENANCE SPECIAL TOOLS LIST (Not applicable)
	V.	DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE REPAIR PARTS LIST
Group	01.	Engine, engine mount, fuel tank, coupling, shaft and collar
	02.	Gear reducer, clutch and shifter lever, pump; and pump bracket
		Gear reducer

04.	Valves, fittings, hose assemblies, and thermometer	19
05.	Hand spray attachment and flexible hose	20
06.	Fuel tank, pressure gage, air pump, valves, lines, and fittings	21
07.	Temperature control assembly	23
08.	Burner assembly	24
09.	Intervchicular cable, lights, reflectors, and wiring harness	24
10.	Spring, hanger assemblies, spring and axle clamp, and U-bolt	26
11.	Wheel, axle, and hub assemblies	27
12.	Tank, lid, support jacks, and frame	28
VI.	DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE SPECIAL TOOLS LIST (Not applicable)	
VII.	FEDERAL STOCK NUMBER AND REFERENCE NUMBER INDEX	

1. Scope

a. This manual lists repair parts, special tools, test and support equipment required for the performance of organizational, direct support, general support, and depot maintenance of the heating kettle.

b. Repair parts listed represent those authorized for use at indicated maintenance levels and will be requisitioned on an "as required" basis until stockage is justified by demand in accordance with AR 710-2.

2. General

This repair parts and special tools list is divided into the following sections:

a. Prescribed Load Allowance List—Section II. Not applicable.

b. Repair Parts List—Section III. A list of repair parts authorized at the organizational level for the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of assembly groups in ascending numerical sequence, with the parts in each group listed in figure and item number sequence.

c. Special Tools, Test and Support Equipment—Section IV. Not applicable.

d. Repair Parts List—Section V. A list of repair parts authorized at the direct support, general support, and depot levels for the performance of maintenance. The list also includes parts which must be removed for the replacement of the authorized parts. Parts lists are composed of assembly groups in ascending numerical sequence, with parts in each group listed in figure and item number sequence.

e. Special Tools, Test and Support Equipment—Section VI. Not applicable.

f. Federal Stock Number and Reference Number Index—Section VII.

A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alpha-numeric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and / or item number appearance.

3. Explanation of Columns

a. Source, Maintenance Codes (SMR).

The SMR code is a five letter code consisting of three parts consisting of a (1) position maintenance code, a two (2) position maintenance code, and one (1) position recoverability code. The maintenance codes are listed in this RPSTL assignment. The recoverability codes and maintenance codes are requisitioned, with justification, through supply channels by use of the maintenance code and part number. Such supplies are normally stocked.

(1) *Source code.* Indicated the source of acquiring support items for maintenance or overhaul of end items. Source code is indicated in the first and second positions of the SMR code.

Code	Description
PA	Item procured and stocked for known usage.
PR	Item procured and stocked because essentiality of quantity be available.
PC	Item procured and stocked would be coded PA except in nature.
PD	Support item, exclusively procured for initial issue or outfitting, stocked only for replenishment.
PE	Support equipment for initial issue or outfitting maintenance repair activity.
PF	Support equipment which will centrally be maintained.
PG	Item procured and sustained support for applied to an item which, because of shutdown of production, is uneconomical to replace.
KD	An item of depot overhauled purchased separately.
KE	An item of a maintenance kit purchased separately.
KB	Item included in both a kit and a maintenance code.
MO	Item to be manufactured at organizational level.
MF	Item to be manufactured at direct support maintenance level.
MH	Item to be manufactured at general support maintenance level.
MD	Item to be manufactured at depot maintenance level.

tenance level.

AD	Item to be assembled at depot maintenance level.
NA	Item is NOT procured or stocked because the requirements for the item will result in replacement of the next higher assembly.
NB	Item NOT procured or stocked. If not available through salvage, requisition.
XC	Installation drawing, diagram, instruction sheet, or field service drawing that is identified by manufacturer's part number.
XD	A low mortality item that is not stocked. When required, items will be requested and provided through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source supply for any items coded above *except* those coded NA and support items restricted by AR 700-42.

(2) *Maintenance codes.* The maintenance code entered in the *third* position indicates the lowest maintenance level authorized to remove, replace, and use the item. The maintenance code entered in the *fourth* position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used in the *fourth* position, a dash (-) will be entered.

Code	Application / Explanation
C	Item is removed, replaced, used (third position), or complete repair (fourth position) at the organizational level.
F	Item is removed, replaced, used (third position), or complete repair (fourth position) at the direct support maintenance level.
H	Item is removed, replaced, used (third position) or complete repair (fourth position) at the general support maintenance level.
D	Item is removed, replaced, used (third position) or complete repair (fourth position) at the depot maintenance level.
L	Repair restricted to designated specialized repair activity (fourth position).
Z	Non-repairable. No repairs authorized (fourth position).
B	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for maintenance of this item (fourth position).

(3) *Recoverability code.* The recoverability code entered in the *fifth* position indicates the disposition action on unserviceable items.

Code	Definition
Z	Non-repairable item. When unserviceable, condemn and dispose at the level indicated in position three (3).

	repairable, condemn and support level.
H	Repairable item. When repairable, condemn and support level.
D	Repairable item. When beyond capability, return to depot disposal not authorized.
L	Repairable item. Repair disposal not authorized. Specialized repair activity.
A	Item requires special handling procedures because of precious metal content, critical material, or hazardous.

b. *Federal Stock Number.* In stock number assigned to the item for requisitioning purposes.

c. *Description.* Indicates the item and a minimum description required. The last line indicates the item followed by the applicable Federal Stock Number (FSN) in parentheses. The FSN is used as an element in the item name to designate manufacturer or distributor, agency, etc., and is identified by the item. Items that are included in kits are identified below the name of the kit or set. Each item in the kit or set is identified by its item name.

d. *Unit of Measure (U/M).* The standard or basic quantity by which the item is used in performing the function. This measure is expressed by a character alphabetical abbreviation, etc., and is the basis used to increase allowances in subsequent columns.

e. *Quantity Incorporated in Illustration.* The quantity of the item used in the illustration figure, which may be an assembly group or an assembly. This quantity is entered in this column in lieu of a quantity. If a specific quantity is applicable, it is entered.

f. *15-Day Organizational Allowances.*

(1) Items authorized for initial stockage are marked with an asterisk in the allowance column.

(2) The allowance column is divided into four subcolumns. Indicated in the total quantity of special tools, number of equipments supplied, etc., applicable).

g. *30-Day DS/GS Maintenance Allowances.*

-Year Allowances Per 100 Equip- Contingency Planning Purposes.

Items authorized for use as required but initial stockage are identified with an in the allowance column.

This column indicates the total quantity of tools required for distribution and con-
planning purposes. (Not applicable).

Depot Maintenance Allowances Per 100 ent

Items authorized for use as required but initial stockage are identified with an in the allowance column.

This column indicates the total quantity of tools authorized for depot maintenance of
ipments. (Not applicable).

5-339-14	Operator, Organizational, Direct Support, and General Support Maintenance
5-256-14	Operator, Organizational, Direct Support, and General Support Maintenance
	Engine, Gasoline, 1½ HP, Military Standard Models
5-256-24P	Operator, Organizational, Direct Support, and General Support Maintenance
	Repair Parts and Special Tools List, Engine, Gasoline, 1½ HP, Military
	Models
2803-256-12	Lubrication Order
339-12	Lubrication Order

How to Locate Repair Parts

When Federal stock numbers or reference
is unknown:

Using the table of contents determine the
group within which the repair part
This is necessary since illustrations are
for assembly groups, and listings are
into the same groups.

Find the illustration covering the assembly
which the repair part belongs.

Identify the repair part on the illustration
the illustration figure and item number of
r part.

Using the repair parts listing, find the
group to which the repair part belongs
e the illustration figure and item number
the illustration.

When the Federal stock number or reference
is known:

Using the Index of Federal Stock Numbers
Reference Numbers find the pertinent Federal

4. Special Information

a. The basis of issue for authorized sp
test, and support equipment, is the num
items of equipment supported and the
maintenance personnel allocated to pe
required maintenance operations.

b. Parts which require manufacture o
of a maintenance level higher than that
for installation will indicate in the sour
the higher maintenance level.

c. Repair parts kits and gasket sets ap
last entries in the repair parts listing for
or assembly to which they apply.

d. The following publications pertain
heating kettle and its components:

stock number or reference number. This
ascending FSN sequence followed by
reference numbers in alpha-numeric
cross-referenced to the illustration figure
and item number.

(2) Using the repair parts listing
assembly group of the repair part
illustration figure number and item
referenced in the Index of Federal Stock
and Reference Numbers.

6. Recommendations for Manual Publications Improvements

You can improve this manual by calling
to errors and by recommending improve
using DA Form 2028 (Recommendations
to Publications) or by a letter, and mail
to Commanding General, U.S. Army
Equipment Command, ATTN: AMS
4300 Goodfellow Boulevard, St. Louis, MO
A reply will be furnished directly to you

Major General, United States Army
De Adjutant General

tribution:

To be distributed in accordance with DA Form 12-25B, (qty rqr block no. 422)
Organizational maintenance requirements for Heaters, Bituminous.

SMR CODE	FEDERAL STOCK NUMBER	DESCRIPTION	USABLE ON CODE	UNIT OF MEAS	QTY INC IN UNIT	15-DAY O. MAINT	
						(a)	(b)
						1-5	6-2
		SECTION III - REPAIR PARTS FOR ORGANIZATIONAL MAINTENANCE					
		GROUP 01 - ENGINE, ENGINE MOUNT, FUEL TANK, COUPLING, SHAFT, AND COLLAR					
PAOZZ	5305-068-0502	SCREW, CAP, HEXAGON HEAD; ENGINE MTG MS90725-6 (96906)		EA	12	*	
PAOZZ	5310-582-5965	WASHER, FLAT; ENGINE MTG SCREW MS35338-44 (96906)		EA	12	*	
PAOZZ		SCREW, CAP, HEXAGON HEAD; TAILPIPE MTG MS90726-6 (96906)		EA	2	*	
PAOZZ	5310-582-5965	WASHER, FLAT; TAILPIPE MTG SCREW MS35338-44 (96906)		EA	2	*	
XBOZZ		TAILPIPE; ENGINE EXHAUST 19012D2000 (15277)		EA	1		
PAOHH	2805-068-7510	ENGINE, GASOLINE 1A08 (97403)		EA	1	*	
PAOZZ	5305-269-3211	SCREW, CAP, HEXAGON HEAD; ENGINE MOUNT MTG MS90725-60 (96906)		EA	4	*	
PAOZZ	5310-637-9541	WASHER, FLAT; ENGINE MOUNT MTG SCREW MS35338-46 (96906)		EA	4	*	
XBOZZ		MOUNT; ENGINE 13219E3377 (97403)		EA	2		
PAOZZ		FITTING, HOSE; BRASS 30182-2-4B (30780)		EA	1	*	
PAOZZ	4720-913-5910	HOSE, RUBBER, FUEL MILH13444TYPE1 (81348)		EA	1	*	
PAOZZ		FITTING, HOSE; BRASS 3018-2-4B (30780)		EA	1	*	
PAOZZ	5310-761-6882	NUT, HEXAGON; HOLDDOWN BAR MTG SCREW MS51967-2 (96906)		EA	4	*	
PAOZZ	5310-582-5965	LOCKWASHER; HOLDDOWN BAR MTG SCREW MS35338-44 (96906)		EA	4	*	
XBOZZ		BAR, TANK, HOLDDOWN 19012Z2076 (15277)		EA	2		
PAOZZ	5305-225-3839	SCREW, CAP, HEXAGON HEAD; HOLDDOWN BAR MS90725-8 (96906)		EA	4	*	
PAOZZ	2910-451-8060	CAP, GASOLINE TANK 426 (00165)		EA	1	*	
XBOOF		TANK, GASOLINE 804 (00165)		EA	1		
PAOZZ	3010-426-0660	COUPLING, FLEXIBLE 20YD31 (21444)		EA	1	*	
XBOZZ		COLLAR, SHAFT SC3-4 (71176)		EA	1		
XBOZZ		SHAFT, EXTENSION 1901ZZZ069 (15277)		EA	1		
		GROUP 02 - GEAR REDUCER, CLUTCH AND SHIFTER LEVER, PUMP, AND PUMP BRACKET					
PAOZZ	5310-880-7744	NUT, HEXAGON; GEAR REDUCER MTG STUD		EA	4	*	

SWR CODE	STOCK NUMBER	DESCRIPTION	USABLE ON CODE	UNIT OF MEAS	QTY INC IN UNIT	MAINTENANCE		
						(a)	(b)	
		REF NUMBER & MFR CODE				1-5	6-20	?
PAOZZ	5310-407-9566	WASHER, LOCK; GEAR REDUCER MTG STD NUT M35338-45 (96906)		EA	4	*	*	
PAOFF	3020-422-9715	REDUCER, GEAR 467705 (24617)		EA	1	*	*	
PAOZZ		PLUG, OIL LEVEL 59529 (24617)		EA	1	*	*	
PAOZZ	5365-477-0327	PLUG, GREASE 52152 (24617)		EA	1	*	*	
PAOZZ		PLUG, DRAIN 51309 (24617)		EA	1	*	*	
PAOZZ		PLUG, VENT 152058 (24617)		EA	1	*	*	
PAOZZ	4730-287-1649	ELBOW, PIPE, STREET; GEAR REDUCER, 90 DEG, 1/8 NPT M39230-1 (96906)		EA	2	*	*	
PAOZZ		PLUG, DRAIN 51309 (24617)		EA	1	*	*	
PAOZZ		NUT, HEXAGON; CLUTCH LEVER MTG SCREW M51988-8 (96906)		EA	1	*	*	
PAOZZ	5310-637-9541	WASHER, LOCK; LEVER MTG SCREW M35338-46 (96906)		EA	1	*	*	
PAOZZ		WASHER, FLAT; LEVER MTG SCREW M527183-15 (96906)		EA	4	*	*	
MOOZZ		SPACER; LONG, LEVER MTG SCREW MANUFACTURE FROM		EA	1			
PAOZZ	4710-277-7866	PIPE, STEEL, 1/2 IN. ID, 2 1/2 IN. REQUIRED		EA		*	*	
MOOZZ		SPACER; SHORT, LEVER MTG SCREW MANUFACTURE FROM		EA	1			
PAOZZ	4710-277-7866	PIPE, STEEL, 1/2 IN. ID, 2 IN. REQUIRED		EA		*	*	
				EA	1	*	*	
				EA	1			
				EA	1	*	*	
				EA	3			
				EA	3			
				EA	1			
				EA	1			
				EA	1	*	*	
				EA	1			
				EA	1			
				EA	1			
				EA	1			
				EA	1			

CODE	STOCK NUMBR	REF NUMBER & MFR CODE	USABLE DN CODE	OF MEAS	IN UNIT	(c) 1-5	(b) 6-20
XAOZZ		DISC, FRICTION 235303 (24617)		EA	1		
XAOZZ		PLATE, PRESSURE 235306 (24617)		EA	1		
XAOZZ		WASHER, THRUST 235312 (24617)		EA	1		
XAOZZ		SLEEVE, ACTUATING 235311 (24617)		EA	1		
XAOZZ		CAM AND SLIP RING ASSEMBLY 235313 (24617)		EA	1		
XAOZZ		BALL, ACTUATING 431005 (24617)		EA	19		
XAOZZ		WASHER, BELLEVILLE 235309 (24617)		EA	1		
XAOZZ		CASE, DUST SEAL 235326 (24617)		EA	1		
XAOZZ		ELEMENT, DUST SEAL 235325 (24617)		EA	1		
XAOZZ		SLEEVE, ADJUSTING 235307 (24617)		EA	1		
XAOZZ		SETSCREW, ADJUSTING 400656 (24617)		EA	2		
PAOZZ	5305-782-9495	SCREW, CAP, HEXAGON HEAD; PUMP MTG MS90725-111 (96906)		EA	4		*
PAOZZ	5310-584-5272	LOCKWASHER, PUMP MTG SCREW MS35338-48 (96906)		EA	4		*
PAOZZ	5310-880-7744	NUT, HEXAGON, PUMP BRACKET MTG MS51967-5 (96906)		EA	4		*
PAOZZ	5310-407-9566	WASHER, FLAT, PUMP BRACKET MTG MS35388-45 (96906)		EA	4		*
XBOZZ		BRACKET, PUMP 30H182 (01942)		EA	1		
PAOFF		PUMP, ASPHALT 10DR (01942)		EA	1		*
		GROUP 03 - PUMP AND GEARBOX BASE AND MOUNTING PLATE					
PAOZZ	5305-964-0119	SCREW, TAPPING, THREAD CUTTING; INSTRUCTION PLATE MTG MS24629-10 (96906)		EA	4		*
PAOZZ		PLATE, INSTRUCTION, PUMP DISCHARGE VALVE 13219E3381 (97403)		EA	1		*
PAOZZ		SCREW, DRIVE, PLATE MTG AN535-6-4 (88044)		EA	4		✓
XBOZZ		PLATE, TRANSPORTATION; HEATING KETTLE 1901222063 (15277)		EA	1		
		GROUP 04 - VALVES, FITTINGS, HOSE ASSEMBLIES, AND THERMOMETER					
PAOZZ	4730-278-4774	ELBOW, UNION, 90 DEG, 1 IN. NPT 1282 (14959)		EA	1		*
PAOZZ		HOSE ASSEMBLY, FLEXIBLE 13219E3380 (96906)		EA	1		*

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REF NUMBER & MFR CODE	(4) USABLE CN CODE	(5) UNIT OF MEAS	(6) QTY INC IN UNIT	(7) 15-DAY ORG. MAINTENANCE	
						(a)	(b)
						1-5	6-20
PAOZZ	4730-187-7599	COUPLING, STRAIGHT; 1 IN. NPT WWP521 (81348)		EA	1	*	*
PAOZZ	4730-288-7180	NIPPLE, PIPE; 1 IN. NPT, 8 IN. LG, STEEL WWH351 (81348)		EA	1	*	*
PAOZZ		NIPPLE, PIPE; 1 IN. NPT, 5 1/2 IN. LG, STEEL MS51953-131 (96906)		EA	1	*	*
XBOZZ		PLATE, FLOW INDICATOR; VALVE 1901222087 (15277)		EA	1		
XBOZZ		HANDLE, VALVE 605 (29215)		EA	1		
XBOZZ		RING, STOP; VALVE 1546C (29215)		EA	1		
PAOZZ		VALVE, 3-WAY; 1 IN. NPT, 3 PORT FIG605-1 (29215)		EA	1	*	*
PAOZZ	4730-196-2059	NIPPLE, CLOSE; 1 IN. NPT, STEEL MS51953-121 (96906)		EA	1	*	*
PAOZZ	4730-221-5011	ELBOW, STREET; 90 DEG, 1 IN. NPT, STEEL MS51952-6 (96906)		EA	1	*	*
PAOZZ	4730-196-1556	NIPPLE, PIPE; 1 IN. NPT, 5 IN. LG, STEEL WWH351 (81348)		EA	1	*	*
PAOZZ	4730-189-2599	UNION, CLOSED; 1 IN. NPT, STEEL FIG463 (26403)		EA	1	*	*
PAOZZ		HOSE ASSEMBLY, FLEXIBLE FIG341-4 (41592)		EA	1	*	*
PAOZZ		VALVE, DRAIN; 1 1/2 IN. NPT 4 (70142)		EA	1	*	*
PAOZZ	4730-277-8891	NIPPLE, PIPE; 1 1/2 IN. NPT, 3 IN. LG, STEEL MS51953-172 (96906)		EA	1	*	*
XBOZZ		PLATE, FLOW INDICATOR; VALVE 1901222087 (15277)		EA	1		
XBOZZ		HANDLE, VALVE 605 (29215)		EA	1		
XBOZZ		RING, STOP; VALVE 1546C (29215)		EA	1		
PAOZZ		VALVE, 3-WAY; 1 1/2 IN. NPT, 3 PORT FIG605-1-1-2 (29215)		EA	1	*	*
PAOZZ	4730-054-2027	NIPPLE, PIPE; 1 1/2 IN. NPT, 9 IN. LG, STEEL MS51953-181 (96906)		EA	1	*	*
PAOZZ	6685-236-9089	THERMOMETER 30-6360BHTS12 (38056)		EA	1	*	*
PAOZZ	4730-231-5654	REDUCER, PIPE; 1 IN. NPT X 3/4 IN. NPT, STEEL MS39232-9 (96906)		EA	1	*	*
PAOZZ		NIPPLE, PIPE; 1 IN. NPT, 8 IN. LG, STEEL MS51953-134 (96906)		EA	1	*	*

SWR CODE	FEDERAL STOCK NUMBER	DESCRIPTION	USABLE ON CODE	UNIT OF MEAS	QTY INC IN UNIT	15-DAY ORGA MAINTENANCE	
						(a)	(b)
						1-5	6-20
REF NUMBER & MFR CODE							
AO0F		HAND SPRAY ATTACHMENT 19012C2000 (15277)		EA	1	*	*
AO2Z	4730-231-2412	CAP, PIPE; HAND SPRAY, 3/4 IN. STEEL WWP521 (81348)		EA	1	*	*
AO2Z		NOZZLE, SPRAY: YEE-JET H3-8U50120 (82247)		EA	2	*	*
BO2Z		SPRAY BAR WELDMENT 19012CB000 (15277)		EA	1		
AO2Z		HANDLE ASSEMBLY; SPRAY BAR 19012CA000GP2 (15277)		EA	1	*	*
AO2Z	5310-088-1251	NUT, HEXAGON; HANDLE ROD MTG SCREW MS51922-1 (96906)		EA	1	*	*
AO2Z	5310-809-4058	WASHER, FLAT; HANDLE ROD MTG SCREW MS27183-10 (96906)		EA	1	*	*
BO2Z		ROD, HANDLE 19012CA005 (15277)		EA	1		
AO2Z	5310-809-4058	WASHER, FLAT; HANDLE ROD MTG SCREW MS27183-10 (96906)		EA	1	*	*
AO2Z	5305-226-7234	SCREW, CAP, HEXAGON HEAD; HANDLE ROD MTG MS90725-26 (96906)		EA	1	*	*
BO2Z		BRACKET, HANDLE 19012CA001-2 (15277)		EA	1		
AO2Z		VALVE, BALL FIG700-5B3-4 (37239)		EA	1	*	*
AO2Z	5310-761-6882	NUT, HEXAGON; HANDLE BRACKET MTG, U-BOLT MS51967-2 (96906)		EA	2	*	*
AO2Z	5310-582-5965	WASHER, LOCK; HANDLE BRACKET MTG, U-BOLT MS35338-44 (96906)		EA	2	*	*
AO2Z		U-BOLT; HANDLE BRACKET MTG 19012C2009 (15277)		EA	1	*	*
BO2Z		PIPE, EXTENSION; SPRAY BAR 19012C2002 (15277)		EA	1		
AO2Z		HANDLE ASSEMBLY; SPRAY BAR 19012CA000GP1 (15277)		EA	1	*	*
AO2Z	5310-081-1251	NUT, HEXAGON; HANDLE ROD MTG SCREW MS51922-1 (96906)		EA	1	*	*
AO2Z	5310-809-4058	WASHER, FLAT; HANDLE ROD MTG SCREW MS27183-10 (96906)		EA	1	*	*
BO2Z		ROD, HANDLE 19012CA005 (15277)		EA	1		
AO2Z	5310-809-4058	WASHER, FLAT; HANDLE ROD MTG SCREW MS27183-10 (96906)		EA	1	*	*
AO2Z	5305-226-7234	SCREW, CAP, HEXAGON HEAD; HANDLE ROD MTG MS90725-26 (96906)		EA	1	*	*
BO2Z		BRACKET, HANDLE 19012CA001-1 (15277)		EA	1		

(1) SWR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	USABLE ON CODE	(4) UNIT OF MEAS	(5) QTY INC IN UNIT	15-DAY OF MAINT	
						(a)	(b)
		REF NUMBER & MFR CODE				1-5	6-2
		GROUP 06 - FUEL TANK, PRESSURE GAGE, AIR PUMP, VALVES, LINES AND FITTINGS					
PAOZZ		PET COCK: AIR BLEED DC601-2 (93061)		EA	1	*	
XBOZZ		REDUCER, PIPE: PET COCK MTG, 1/2 IN. NPT X 3/4 IN. NPTM 209DS1258 (93061)		EA	1		
PAOZZ		CAP, PRESSURE RELEASE: FUEL TANK 1901ZEZ000 (15277)		EA	1	*	
PAOZZ	4730-192-1472	NIPPLE, PIPE: CLOSED, 2 IN. NPT WVN351 (81348)		EA	1	*	
PAOZZ	4820-451-4654	VALVE, POP OFF: FUEL TANK, 55 PSI, 1/2 IN. NPT, BRASS 214598 (38056)		EA	1	*	
PAOZZ		GAGE, PRESSURE: FUEL TANK, 0 TO 60 PSI, 2 1/2 IN. DIAL 8197882 (73475)		EA	1	*	
XBOZZ		NUT, LONG FLARE: TUBING, 1/4 IN. BRASS 41FS4 (93061)		EA	1		
XBOZZ		ADAPTER, PIPE: FLARED NUT 48F4-4 (93061)		EA	2		
XBOZZ		TEE, PIPE: PRESSURE GAGE 2203P4 (93061)		EA	1		
PAOZZ		CONNECTOR, PIPE, STRAIGHT: PRESSURE GAGE MTG, 1/4 IN. TUBE X 1/4 IN PIPE 48FS4-4 (93061)		EA	1	*	
XBOZZ		NUT, LONG FLARE: TUBING, 1/4 IN. BRASS 41FS4 (93061)		EA	1		
XBOZZ		TUBING, COPPER: TEMPERATURE CONTROL TO PRESSURE GAGE, 1/4 IN. X .030 WALL, 20 IN. LG 1901ZZZ007-3 (15277)		EA	1		
XBOZZ		ADAPTER, PIPE: FLARED NUT 48F4-4 (93061)		EA	1		
PAOZZ		CONNECTOR, PIPE, STRAIGHT: TUBE MTG, 1/4 IN. TUBE X 1/4 IN. PIPE 48FS4-4 (93061)		EA	1	*	
PAOZZ	5310-422-2560	NUT, LONG FLARE: TUBING, 1/4 IN. BRASS 41FL4 (93061)		EA	2	*	
PAOZZ		TUBING, COPPER: FUEL TANK TO VALVE 1901ZZZ007-1 (15277)		EA	1	*	
PAOZZ		CONNECTOR, PIPE, STRAIGHT: TUBE TO VALVE, 1/4 IN. TUBE X 1/4 IN. PIPE 48FS4-4 (93061)		EA	2	*	
PAOZZ		VALVE, GLOBE: FUEL TANK, 1/4 IN. NPT, BRASS 401-6 (15277)		EA	1	*	

SW-4 CODE	FEDERAL STOCK NUMBER	DESCRIPTION	USABLE OR CODE	UNIT OF MEAS	QTY INC IN UNIT	MAINTENANCE	
						(a) 1-5	(b) 6-20
REF NUMBER & MFR CODE							
PA0ZZ	5310-422-2560	NUT, LONG FLARE: TUBING, 1/4 IN., BRASS 41FL4 (93061)		EA	2	*	
PA0ZZ		TUBING, COPPER: VALVE TO TEMPERATURE CONTROL 1901ZZ2007-2 (15277)		EA	1	*	
X00ZZ		CONNECTOR, PIPE, STRAIGHT: TUBE TO TEMPERATURE CONTROL 48FS4-4 (93061)		EA	1		
X00ZZ		HOSE ASSEMBLY, TORCH: HAUCH MOL WHD34 14982X6 (27695)		EA	1		
X00ZZ		BUSHING, PIPE: HOSE ASSEMBLY 209PS8-4 (93061)		EA	1		
X00ZZ		NIPPLE, PIPE: HOSE ASSEMBLY 216P4 (93061)		EA	1		
X00ZZ		ELBOW, PIPE: TEMPERATURE CONTROL 1202PS4-4 (93061)		EA	1		
X00ZZ		BUSHING, PIPE: HOSE ASSEMBLY 209PS8-4 (93061)		EA	1		
X00ZZ		NIPPLE, PIPE: HOSE ASSEMBLY 216P4 (93061)		EA	1		
X00ZZ		ELBOW, PIPE: BURNER ASSEMBLY 202PS4-4 (93061)		EA	1		
PA0ZZ	4730-905-2692	COUPLING, PIPE: THERMOCOUPLE MTG MS39233-5 (96906)		EA	1	*	
PA0ZZ	4730-288-6983	NIPPLE, PIPE: THERMOCOUPLE MTG MS51953-111 (96906)		EA	1	*	
PA0ZZ	5310-982-4938	NUT, SQUARE: TEMPERATURE CONTROL ASSEMBLY MTG, 1/4-20 THD SIZE MS27040-10 (96906)		EA	2	*	
PA0ZZ	5310-582-5965	LOCKWASHER: TEMPERATURE CONTROL ASSEMBLY MTG SCREW, 1/4 IN. MS35338-44 (96906)		EA	2	*	
PA0ZZ	5305-988-1727	SCREW, PAN HEAD: TEMPERATURE CONTROL ASSEMBLY MTG, 1/4-20 UNC X 1 IN. LG MS35206-283 (96906)		EA	2	*	
PA0ZZ	4320-451-2729	PUMP, AIR, HAND: FUEL TANK, 2 IN. SIZE 49 (70142)		EA	1	*	
X00ZZ		PLATE, CAUTION: FUEL TANK 1901ZZ2088 (15277)		EA	1		
PA0ZZ	5310-880-7744	NUT, HEXAGON: FUEL TANK MTG SCREW, 5/16-18 NC MS51967-5 (96906)		EA	4	*	
PA0ZZ	5310-407-9566	LOCKWASHER: FUEL TANK MTG SCREW, 5/16 IN. MS35338-45 (96906)		EA	4	*	
PA0ZZ	5310-225-8499	SCREW, CAP, HEXAGON HEAD: FUEL TANK MTG, 5/16-18 X 1 IN. LG MS90725-34 (96906)		EA	4	*	
X00ZZ		TANK, FUEL, PRESSURIZED 1901FZZ000 (15277)		EA	1		
PA0ZZ	4730-221-2137	PLUG, PIPE: FUEL TANK DRAIN, 1/4 IN. NPT MS20913-25 (96906)		EA	2	*	

(1) SWR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REF NUMBER & MFR CODE	(4) UNIT OF MEAS ON CODE	(5) QTY INC IN UNIT	15-DAY O MAINT	
					(6)	(7)
					1-5	6-7
		GROUP 07 - TEMPERATURE CONTROL ASSEMBLY				
PA00F	6685-405-1695	CONTROL ASSEMBLY, TEMPERATURE GWSSJ369AS8 (45809)	EA	1	*	
PA02Z		KNOB: TEMPERATURE CONTROL ZC26 (45809)	EA	1	*	
PA02Z	5305-984-6213	SCREW, CAP: COVER MTG MS35206-266 (96906)	EA	4	*	
XB02Z		COVER: TEMPERATURE CONTROL GWS10F (45809)	EA	1		
PA02Z		GASKET, COVER: TEMPERATURE CONTROL GWS4 (45809)	EA	1	*	
XB02Z		SCREW, CAP, HEXAGON HEAD SLOTTED: FLANGE MTG L98 (45809)	EA	2		
XB02Z		O RING: FLANGE ACC165 (45809)	EA	1		
XB02Z		FLANGE, ELEMENT L4F (45809)	EA	1		
PA02Z	6685-257-0188	ELEMENT, THERMOCOUPLE 445KLP110-5 (45809)	EA	1	*	
XA02Z		STUFFING BOX 3-4-217105 (45809)	EA	1		
PA02Z	5305-638-4027	SCREW, MACHINE: ROUNDHEAD, VALVE MTG 5800-30-31 (31741)	EA	4	*	
PA02Z	5310-045-3296	LOCKWASHER: VALVE MTG MS35338-43 (96906)	EA	4	*	
XA02Z		VALVE ASSEMBLY: TEMPERATURE CONTROL GWSSJ36952 (45809)	EA	1		
XA02Z		MECHANISM ASSEMBLY: TEMPERATURE CONTROL GWSSJ36956 (45809)	EA	1		
PA02Z	5305-059-4568	SCREW, MACHINE: FLATHEAD, RELIEF VALVE MTG MS35190-253 (96906)	EA	2	*	
XB02Z		VALVE ASSEMBLY, RELIEF GWSSJ36957 (45809)	EA	1		
XA02Z		ADAPTER 120B (45809)	EA	1		
PA02Z	5305-253-5612	SCREW, DRIVE: PLATE MTG ANSJ5-2-4 (88044)	EA	2	*	
XB02Z		PLATE, RATING: TEMPERATURE CONTROL 40-108 (45809)	EA	1		
XA02Z		CASE: TEMPERATURE CONTROL GWSSJ369-11 (45809)	EA	1		
		GROUP 08 - BURNER ASSEMBLY				
XB02Z		CONNECTOR, PIPE, STRAIGHT; BURNER VALVE, 1/4 IN NPT 2083-4-4S (00624)	EA	1		

FEDERAL STOCK NUMBER	DESCRIPTION	USABLE ON CODE	UNIT OF MEAS	QTY INC IN UNIT	MAINTENANCE ALW				
					(a)	(b)	(c)	(d)	
					1-5	6-20	21-50	51-100	
REF NUMBER & MFR CODE									
	ELBOW, PIPE, STREET: 90 DEG, BURNER VALVE, 1/4 IN. NPTF, 1/4 IN. NPTM 1-4COS (93061)		EA	1					
	NIPPLE, PIPE: BURNER VALVE, 1/4 IN. NPT 2084-4S7-8 (00624)		EA	1					
	BURNER ASSEMBLY WHD34 (27695)		EA	1	*	*	*	*	
	VALVE: BURNER WHD2 (27695)		EA	1					
	GROUP 09 - INTERVEHICULAR CABLE, LIGHTS, REFLECTORS AND WIRING HARNESS								
00-038-3914	CABLE ASSEMBLY, INTERVEHICULAR 7728811 (19207)		EA	1	*	*	*	*	
0-761-6882	NUT, HEXAGON: RECEPTACLE AND COVER MTG SCREW MS51967-2 (96906)		EA	4	*	*	*	*	
0-582-5965	LOCKWASHER: RECEPTACLE AND COVER MTG SCREW MS35338-44 (96906)		EA	4	*	*	*	*	
05-225-3839	SCREW, CAP, HEXAGON HEAD: RECEPTACLE AND COVER MTG MS90725-8 (96906)		EA	4	*	*	*	*	
	RECEPTACLE: ELECTRICAL MS75021-1 (96906)		EA	1					
	COVER, RECEPTACLE: ELECTRICAL 7731428 (77820)		EA	1					
	SCREW, DRIVE: REFLECTOR MTG MS21318-41 (96906)		EA	4	*	*	*	*	
	REFLECTOR, RED MS35387-1 (96906)		EA	4					
	REFLECTOR, AMBER MS35387-2 (96906)		EA	4					
10-761-6882	NUT, HEXAGON: CLAMP MTG SCREW MS51967-2 (96906)		EA	2	*	*	*	*	
	CLAMP, CONDUIT 920 (82059)		EA	2					
	SCREW, MACHINE: CLAMP MTG MS35206-281 (96906)		EA	2	*	*	*	*	
	CONDUIT, STEEL: THIN WALL, 1/2 IN. DIA, 78 IN. LG 1-2ENT (89481)		IN	78					
	TUBING, PLASTIC: 1/2 IN. DIA, 72 IN. LG 21T831 (81348)		IN	72					
	NUT, HEXAGON: LIGHT MTG SCREW MS35650-302 (96906)		EA	78	*	*	*	*	
10-045-3296	LOCKWASHER: LIGHT MTG SCREW MS35338-43 (96906)		EA	78	*	*	*	*	
05-616-4831	SCREW, MACHINE: LIGHT MTG MS35266-65 (96906)		EA	78	*	*	*	*	
20-727-3288	LIGHT, MARKER: RED, 24 VOLTS MS35424-2 (96906)		EA	4	*	*	*	*	

DESCRIPTION

SMR CODE	STOCK NUMBFR	REF NUMBER & MFR CODE	USABLE ON CODE	OF MEAS	INC IN UNIT	(d) 1-5	(b) 6-2
PA0ZZ	6220-726-1916	LIGHT, MARKER; RED, 24 VOLTS MS35423-2 (96906)		EA	7	*	
PA0ZZ	6240-019-0877	LAMP; BLACKOUT, STOP AND TURN SIGNAL MS15570-1251 (96906)		EA	2	*	
PA0ZZ	6240-295-1184	LAMP; STOP AND TAILLIGHT 1034 (08806)		EA	1	*	
PA0ZZ	6220-577-3434	LIGHT, MARKER; AMBER, 24 VOLTS MS35423-1 (96906)		EA	4	*	
PA0ZZ	6220-577-3435	LIGHT, MARKER; AMBER, 24 VOLTS MS35424-1 (96906)		EA	4	*	
PA0ZZ	6220-466-0310	LIGHT, STOP-TURN 0433 (81834)		EA	2	*	
PA0ZZ	6220-337-6471	LIGHT, STOP-TURN MS51330-1 (96906)		EA	2	*	
XB0ZZ		CONNECTOR ASSEMBLY MS27144-1 (96906)		EA	18		
XB0ZZ		CONNECTOR ASSEMBLY MS27142-2 (96906)		EA	6		
PA0ZZ	5935-925-6494	TERMINAL MS27148-1 (96906)		EA	2	*	
XB0ZZ		BOARD, TERMINAL 601-4 (75382)		EA	2		
XB0ZZ		BOX, JUNCTION 1901MZ007 (15277)		EA	1		
PA00F		HARNESS, WIRING 1901MAZ000 (15277)		EA	1	*	
XB0ZZ		WIRE ASSEMBLY 1901MBZ000-1 (15277)		EA	2		
XB0ZZ		WIRE ASSEMBLY 1901MBZ000-2 (15277)		EA	2		
XB0ZZ		WIRE ASSEMBLY, GROUND 1901MCZ000 (15277)		EA	2		
XB0ZZ		WIRE ASSEMBLY 1901MDZ000-1 (15277)		EA	3		
XB0ZZ		WIRE ASSEMBLY 1901MDZ000-2 (15277)		EA	1		
XB0ZZ		WIRE ASSEMBLY 1901MDZ000-3 (15277)		EA	2		
XB0ZZ		WIRE ASSEMBLY 1901MDZ000-4 (15277)		EA	2		
XB0ZZ		WIRE ASSEMBLY 1901MDZ000-5 (15277)		EA	2		
XB0ZZ		WIRE ASSEMBLY 1901MDZ000-6 (15277)		EA	1		
XB0ZZ		ADAPTER, CONNECTOR MS27147-1 (96906)		EA	15		
XB0ZZ		BREAKER, CIRCUIT 30056-30STK (13445)		EA	3		

SYD CODE	FEDERAL STOCK NUMBER	DESCRIPTION	USABLE ON CODE	UNIT OF MEAS	QTY INC IN UNIT	1-DAY ORG. MAINTENANCE	
						(a) 1-5	(b) 6-20
		GROUP 10 - SPRING, HANGER ASSEMBLIES, SPRING AND AXLE CLAMP AND U-BOLT					
PAOZZ	4730-172-0034	FITTING, LUBRICATION MS15003-6 (96906)		EA	2	*	*
PAOZZ	5315-839-5622	PIN, COTTER: SHACKLE BOLT MTG MS24665-353 (96906)		EA	2	*	*
PAOZZ	5310-850-6884	NUT, SHACKLE BOLT MS35692-45 (22938)		EA	2	*	*
PAOZZ	5306-136-9800	BOLT, SHACKLE: 9/16-18 UF X 3 7/8 IN. LG 5402-2 (22938)		EA	2	*	*
PAOZZ	5315-839-5822	PIN, COTTER: RIVET MTG, 1/8 X 1 IN. MS24665-353 (96906)		EA	2	*	*
KB0ZZ		RIVET: ROUNDHEAD, 9/16 IN. DIA X 3 IN. LG 5403-1 (22938)		EA	2		
		GROUP 11 - WHEEL, AXLE AND HUB ASSEMBLIES					
PCOZZ	2610-678-1363	TIRE: 700 X 16 MS35388-93 (96906)		EA	2	*	*
PCOZZ	2610-269-7332	TUBE, TIRE: 700 X 16 MS35292-8 (96906)		EA	2	*	*
PAOZZ	5310-732-0560	NUT, STUD: WHEEL MTG, 1/2-20 THD SIZE MS51968-14 (96906)		EA	10	*	*
PAOZZ	5310-584-5272	LOCKWASHER: WHEEL MTG, 1/2 IN. MEDIUM PLAIN MS35338-48 (96906)		EA	10	*	*
KB0ZZ		WHEEL ASSEMBLY: 700 X 16 7387807 (00000)		EA	2		
KB0ZZ		CAP, GREASE 6312 (22938)		EA	2		
PBOFF		AXLE ASSEMBLY: WHEEL 1-2006 (22938)		EA	1	*	*
PAOZZ	5315-285-7161	PIN, COTTER: SPINDLE NUT, 1/8 X 2 IN. MS24665-377 (96906)		EA	2	*	*
PAOZZ		NUT, SPINDLE 4600-2 (22938)		EA	2	*	*
PAOZZ	2530-455-1180	COLLAR, GREASE 6316 (22938)		EA	2	*	*
KB0ZZ		BEAM, AXLE 2006-21 (22938)		EA	1		
PAOZZ		WASHER, SPINDLE 4702-5 (22938)		EA	2	*	*
PAOZZ		BEARING CONE, OUTER 6058 (22938)		EA	2	*	*
PAOZZ	3110-224-5644	BEARING CONE, INNER 6057 (22938)		EA	2	*	*
PAOZZ		SEAL, GREASE 6311 (22938)		EA	2	*	*
PAOZZ	2530-455-1181	HUB ASSEMBLY, WHEEL		EA	2	*	*

SWR CODE	STOCK NUMBER	DESCRIPTION	USABLE ON CODE	UNIT OF MEAS	INC IN UNIT	QUANTITY	
						(a)	(b)
		REF NUMBER & MFR CODE				1-5	6-20
XBOZZ		HUB, STUD AND CUP ASSEMBLY 3603-1 (22938)		EA	2		
PAOZZ		BEARING CUP, OUTER 6151 (22938)		EA	2	*	*
PAOZZ		BEARING CUP, INNER 6152 (22938)		EA	2	*	*
PAOZZ		STUD, WHEEL 6251-3 (22938)		EA	10	*	*
XBOZZ		HUB: WHEEL 3603 (22938)		EA	2		
		GROUP 12 - TANK, LID, SUPPORT JACKS AND FRAME					
XBOZZ		RACK: KETTLE TANK 1901JZ000 (15277)		EA	1		
PAOZZ	5310-761-6882	NUT, HEXAGON: SEPARATOR PLATE MTG SCREW, 1/4-20 THD SIZE MS51967-2 (96906)		EA	3	*	*
PAOZZ	5310-582-5965	LOCKWASHER: SEPARATOR PLATE MTG SCREW, 1/4 IN. MS35338-44 (96906)		EA	3	*	*
PAOZZ	5305-225-3839	SCREW, CAP, HEXAGON HEAD: SEPARATOR PLATE MTG MS90725-8 (96906)		EA	3	*	*
XBOZZ		PLATE, SEPARATOR: NUMBER 1 1901ZZ022 (15277)		EA	1		
XBOZZ		PLATE, SEPARATOR: NUMBER 2 1901CZ000 (15277)		EA	1		
MOOZZ		CHAIN ASSEMBLY, COVER: SAFETY 13219E3384 (97403) MANUFACTURE FROM:		EA	1		
PAOZZ	4010-585-2108	CHAIN, 33 IN. REQUIRED		EA		*	*
PAOZZ	4030-869-1529	HOOK, 2 EA		EA		*	*
PAOZZ		PIN, QUICK RELEASE: TANK LID LG4ST625 (83014)		EA	1	*	*
PAOZZ		LANYARD ASSEMBLY: QUICK RELEASE PIN LW1036-6 (83014)		EA	1	*	*
PAOZZ	5310-761-6882	NUT, HEXAGON: TANK MTG SCREW, 1/4-20 THD SIZE MS51967-2 (96906)		EA	12	*	*
PAOZZ	5310-582-5965	LOCKWASHER: TANK MTG SCREW MS35338-44 (96906)		EA	12	*	*
PAOZZ	5305-225-3839	SCREW, CAP, HEXAGON HEAD: TANK MTG MS90725-8 (96906)		EA	12	*	*
PAOZZ	5310-761-6882	NUT, HEXAGON: SAFETY STUD, 1/4-20 THD SIZE MS51967-2 (96906)		EA	2	*	*
PAOZZ	5310-582-5965	LOCKWASHER: SAFETY STUD, 1/4 IN. MS51967-2 (96906)		EA	1	*	*
PAOZZ		STUD: SAFETY, FUSIBLE SCREW, 1/4-20 THD SIZE, 1 1/2 IN. LG 1901EAC005 (15277)		EA	1	*	*
XBOZZ		LID, MELTING TANK 1901EAC000 (15277)		EA	1		

SKD CODE	FEDERAL STOCK NUMBER	DESCRIPTION	USABLE OR CODE	UNIT OF MEAS	QTY INC IN UNIT	MAINTEN	
						(a) 1-5	(b) 6-20
REF NUMBER & MFR CODE							
PA0ZZ	5310-761-6882	NUT, HEXAGON: TANK VENT MTG SCREW, 1/4-20 THD SIZE MS51967-2 (96906)		EA	4	*	*
PA0ZZ	5310-582-5965	LOCKWASHER: TANK VENT MTG SCREW, 1/4 IN. MS35338-44 (96906)		EA	4	*	*
PA0ZZ	5305-225-3839	SCREW, CAP, HEXAGON HEAD: TANK VENT MTG MS90725-8 (96906)		EA	4	*	*
XB0ZZ		VENT, TANK 1901GZZ000 (15277)		EA	1		
PA0ZZ	5310-761-6882	NUT, HEXAGON: BAFFLE MTG SCREW, 1/4-20 THD SIZE MS51967-2 (96906)		EA	12	*	*
PA0ZZ	5310-582-5965	LOCKWASHER: BAFFLE MTG SCREW MS35338-44 (96906)		EA	12	*	*
PA0ZZ	5305-225-3839	SCREW, CAP, HEXAGON HEAD: BAFFLE MTG MS90725-8 (96906)		EA	12	*	*
XB0ZZ		BAFFLE, HEAT 1901ZZ018 (15277)		EA	2		
XB0ZZ		BAFFLE, HEAT 1901BZZ000-1 (15277)		EA	1		
XB0ZZ		BAFFLE, HEAT 1901BZZ000-2 (15277)		EA	1		
XB0ZZ		BAFFLE, HEAT 1901ZZ048 (15277)		EA	1		
PA0ZZ		CHOCK BLOCK ASSEMBLY TX164B2 (03742)		EA	2	*	*
PA0ZZ		PIN, QUICK RELEASE: JACK, CABLE ATTACHED, 1/4 IN. DIA X 4 9/16 IN. LG BLN4-4-562 (84256)		EA	4	*	*
PA0ZZ		JACK, SUPPORT: REAR 1901DZZ000-1 (15277)		EA	1	*	*
PA0ZZ		JACK, SUPPORT: FRONT 1901DZZ000-2 (15277)		EA	1	*	*
PA0ZZ		CHAIN ASSEMBLY, SAFETY 0212-0425 (80535)		EA	2	*	*
PA0ZZ		COLD SHUT N01-1-4 (13743)		EA	2	*	*
PA0ZZ	5305-253-5618	SCREW, DRIVE: PLATE MTG AN535-6-4 (88044)		EA	4	*	*
XB0ZZ		PLATE, IDENTIFICATION 1901ZZ062 (15277)		EA	1		
PA0ZZ	5305-964-0119	SCREW, TAPPING, THREAD CUTTING: INSTRUCTION PLATE MTG MS24629-10 (96906)		EA	4	*	*
PA0ZZ		PLATE, INSTRUCTION: TANK OUTLET VALVE 13219E33856 (97403)		EA	1	*	*

SWR CODE	STOCK NUMBER	REF NUMBER & MFR CODE	USABLE ON CODE	UNIT OF MEAS	QTY INC IN UNIT	(a)	(b)	(c)	(d)	(e)	(f)
		SECTION V - REPAIR PARTS FOR DS, GS AND DEPOT MAINTENANCE				1-20	21-50	51-100	1-20	21-50	51-100
		GROUP 01 - ENGINE, ENGINE MOUNT, FUEL TANK, COUPLING, SHAFT, AND COLLAR									
PA02Z	5305-068-0502	SCREW, CAP, HEXAGON HEAD; ENGINE MTG MS90725-6 (96906)		EA	12	*	*	*	*	*	*
PA02Z	5310-582-5965	WASHER, FLAT; ENGINE MTG SCREW MS35338-44 (96906)		EA	12	*	*	*	*	*	*
PA02Z		SCREW, CAP, HEXAGON HEAD; TAILPIPE MTG MS90726-6 (96906)		EA	2	*	*	*	*	*	*
PA02Z	5310-582-5965	WASHER, FLAT; TAILPIPE MTG SCREW MS35338-44 (96906)		EA	2	*	*	*	*	*	*
XB02Z		TAILPIPE; ENGINE EXHAUST 1901202000 (15277)		EA	1						
PA02H	2805-068-7510	ENGINE, GASOLINE 1A08 (97403)		EA	1	*	*	*	*	*	*
PA02Z	5305-269-3211	SCREW, CAP, HEXAGON HEAD; ENGINE MOUNT MTG MS90725-60 (96906)		EA	4	*	*	*	*	*	*
PA02Z	5310-637-9541	WASHER, FLAT; ENGINE MOUNT MTG SCREW MS35338-46 (96906)		EA	4	*	*	*	*	*	*
XB02Z		MOUNT; ENGINE 13219E3377 (97403)		EA	2						
PA02Z		FITTING, HOSE; BRASS 30182-2-4B (30780)		EA	1	*	*	*	*	*	*
PA02Z	4720-913-5910	HOSE, RUBBER, FUEL MILH1344TYPE1 (81348)		EA	1	*	*	*	*	*	*
PA02Z		FITTING, HOSE; BRASS 3018-2-4B (30780)		EA	1	*	*	*	*	*	*
PA02Z	5310-761-6882	NUT, HEXAGON; HOLDDOWN BAR MTG SCREW MS51967-2 (96906)		EA	4	*	*	*	*	*	*
PA02Z	5310-582-5965	LOCKWASHER; HOLDDOWN BAR MTG SCREW MS35338-44 (96906)		EA	4	*	*	*	*	*	*
XB02Z		BAR, TANK, HOLDDOWN 1901222076 (15277)		EA	2						
PA02Z	5305-225-3839	SCREW, CAP, HEXAGON HEAD; HOLDDOWN BAR MS90725-8 (96906)		EA	4	*	*	*	*	*	*
PA02Z	2910-451-8060	CAP, GASOLINE TANK 426 (00165)		EA	1	*	*	*	*	*	*
XB00F		TANK, GASOLINE 804 (00165)		EA	1						
PA02Z	3010-426-0660	COUPLING, FLEXIBLE 20T031 (21444)		EA	1	*	*	*	*	*	*
XB02Z		COLLAR, SHAFT SC3-4 (71176)		EA	1						
XB02Z		SHAFT, EXTENSION 1901222069 (15277)		EA	1						
		GROUP 02 - GEAR REDUCER, CLUTCH AND SHIFTER LEVER, PUMP, AND PUMP BRACKET									
PA02Z	5310-880-7744	NUT, HEXAGON; GEAR REDUCER MTG STUD MS51967-5 (96906)		EA	4	*	*	*	*	*	*

STOCK NUMBER	REF NUMBER & MFR CODE	USABLE ON CODE	UNIT OF MEAS	QTY INC IN UNIT	ALLURANCE						ALW PER 100 EQUIP CHTGY
					(a)	(b)	(c)	(d)	(e)	(f)	
10-407-9566	WASHER, LOCK; GEAR REDUCER MTG STUD NUT M535338-45 (96906)		EA	4	1-20	21-50	51-100	1-20	21-50	51-100	
20-422-9715	REDUCER, GEAR 467705 (24617)		EA	1							
	SCREW, CAP, HEXAGON HEAD; HOUSING MTG 53852 (24617)		EA	8							
	LOCKWASHER; HOUSING MTG SCREW 50254 (24617)		EA	8							
	HOUSING, BEARING 79070-02A (24617)		EA	1							
	GASKET; HOUSING 602028-14A (24617)		EA	1							
	SEAL, OIL 150984 (24617)		EA	1							
	SLEEVE; OIL SEAL, OUTPUT SHAFT 411621-08B (24617)		EA	1							
	KEY, OUTPUT SHAFT 55592 (24617)		EA	1							
	BEARING, OUTPUT SHAFT 411626-01B (24617)		EA	1							
	SHIM; OIL SEAL 411623-01R (24617)		EA	1							
	SPACER, OUTPUT SHAFT 411622-08H (24617)		EA	1							
	BEARING, OUTPUT SHAFT 411626-01D (24617)		EA	1							
	SPACER, OUTPUT SHAFT 11622-08H (24617)		EA	1							
	GEAR, DRIVEN 602083-16 (24617)		EA	1							
	RING, LOCK 411637-02C (24617)		EA	1							
	SPACER, OUTPUT SHAFT 411622-08J (24617)		EA	1							
	SHAFT, OUTPUT 602088-01A (24617)		EA	1							
	SCREW, CAP, HEXAGON HEAD; BEARING CLAMP MTG M590725-5 (96906)		EA	4							
	LOCKWASHER; BEARING CLAMP MTG SCREW 419009 (38740)		EA	4							
	CLAMP, BEARING 411625-10A (24617)		EA	1							
	KEY, PINION 51744 (24617)		EA	1							
	BEARING, PINION SHAFT 59863 (24617)		EA	1							
	SLEEVE, OIL SEAL 411621-07B (24617)		EA	1							
	SEAL, OIL, PINION 411620-21A (24617)		EA	1							
	BEARING, PINION 51828 (24617)		EA	1							
	SLINGER, PINION 411610-02C (24617)		EA	1							

SWR CODE	STOCK NUMBER	REF NUMBER & MFR CODE	USABLE ON CODE	UNIT OF MEAS	QTY INC IN UNIT	(a)	(b)	(c)	(d)	(e)	(f)
XBFZZ		SHAFT, PINION; W/GEAR 602082-35 (24617)		EA	1						
PAOZZ		PLUG, OIL LEVEL 59529 (24617)		EA	1	*	*	*	*	*	*
PAOZZ	5365-477-0327	PLUG, GREASE 52152 (24617)		EA	1	*	*	*	*	*	*
PAOZZ		PLUG, DRAIN 51309 (24617)		EA	1	*	*	*	*	*	*
PAOZZ		PLUG, VENT 152058 (24617)		EA	1	*	*	*	*	*	*
PAOZZ	4730-287-1649	ELBOW, PIPE, STREET; GEAR REDUCER, 90 DEG, 1/8 NPT MS39230-1 (96906)		EA	2	*	*	*	*	*	*
PAOZZ		PLUG, DRAIN 51309 (24617)		EA	1	*	*	*	*	*	*
XAFZZ		SCREW, FOOT MOUNTING 53908 (24617)		EA	4						
XAFZZ		WASHER, LOCK; FOOT MTG SCREW 58092 (24617)		EA	4						
XAFZZ		FOOT, MOUNTING; GEAR REDUCER 79035-14A (24617)		EA	1						
XAFZZ		GEAR CASE; GEAR REDUCER 86869-04A (24617)		EA	1						
PAOZZ		NUT, HEXAGON; CLUTCH LEVER MTG SCREW MS51968-8 (96906)		EA	1	*	*	*	*	*	*
PAOZZ	5310-637-9541	WASHER, LOCK; LEVER MTG SCREW MS35338-46 (96906)		EA	1	*	*	*	*	*	*
PAOZZ		WASHER, FLAT; LEVER MTG SCREW MS27183-15 (96906)		EA	4	*	*	*	*	*	*
MOOZZ		SPACER; LONG, LEVER MTG SCREW MANUFACTURE FROM:		EA	1						
PAOZZ	4710-277-7866	PIPE, STEEL, 1/2 IN. ID, 2 1/2 IN. REQUIRED		EA		*	*	*	*	*	*
MOOZZ		SPACER; SHORT, LEVER MTG SCREW MANUFACTURE FROM:		EA	1						
PAOZZ	4710-277-7866	PIPE, STEEL, 1/2 IN. ID, 2 IN. REQUIRED		EA		*	*	*	*	*	*
PAOZZ		SCREW, CAP, HEXAGON HEAD; LEVER MTG 1901222136 (15277)		EA	1	*	*	*	*	*	*
XBOZZ		LEVER W/HANDLE, SHIFT, CLUTCH FR3 (24617)		EA	1						
PAOZZ	3010-426-0662	CLUTCH 35ME (24617)		EA	1	*	*	*	*	*	*
XAOZZ		SCREW, CAP, HEXAGON HEAD; HUB MTG 416546 (24617)		EA	3						
XAOZZ		WASHER, LOCK; HUB MTG SCREW 419009 (24617)		EA	3						
XAOZZ		HUB, CLUTCH COUPLING H35E (24617)		EA	1						
XAOZZ		RING, DRIVE 235302 (24617)		EA	1						
XAOZZ		HUB, DRIVE 235332 (24617)		EA	1						

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION USABLE ON CODE	(4) UNIT OF MEAS	(5) QTY INC IN UNIT	(6) 30-DAY DS MAINT ALLOWANCE			(7) 30-DAY DS MAINT ALLOWANCE		
					(a)	(b)	(c)	(a)	(b)	(c)
					1-20	21-50	51-100	1-20	21-50	51-100
02Z		SETSCREW: DRIVE HUB 400577 (24617)	EA	1						
02Z		BUSHING 235031 (24617)	EA	1						
02Z		SPRING, RELEASE 235323 (24617)	EA	1						
02Z		DISC, FRICTION 235303 (24617)	EA	1						
02Z		PLATE, PRESSURE 235306 (24617)	EA	1						
02Z		WASHER, THRUST 235312 (24617)	EA	1						
02Z		SLEEVE, ACTUATING 235311 (24617)	EA	1						
02Z		CAM AND SLIP RING ASSEMBLY 235313 (24617)	EA	1						
02Z		BALL, ACTUATING 431005 (24617)	EA	19						
02Z		WASHER, BELLEVILLE 235309 (24617)	EA	1						
02Z		CASE, DUST SEAL 235326 (24617)	EA	1						
02Z		ELEMENT, DUST SEAL 235325 (24617)	EA	1						
02Z		SLEEVE, ADJUSTING 235307 (24617)	EA	1						
02Z		SETSCREW: ADJUSTING 400656 (24617)	EA	2						
02Z	5305-782-9495	SCREW, CAP, HEXAGON HEAD: PUMP MTG MS90725-111 (96906)	EA	4	*	*	*	*	*	*
02Z	5310-584-5272	LOCKWASHER: PUMP MTG SCREW MS35338-48 (96906)	EA	4	*	*	*	*	*	*
02Z	5310-880-7744	NUT, HEXAGON: PUMP BRACKET MTG MS51967-5 (96906)	EA	4	*	*	*	*	*	*
02Z	5310-407-9566	WASHER, FLAT: PUMP BRACKET MTG MS35388-45 (96906)	EA	4	*	*	*	*	*	*
02Z		BRACKET, PUMP 30H182 (01942)	EA	1						
OFF.		PUMP, ASPHALT 10DR (01942)	EA	1	*	*	*	*	*	*
02Z		SCREW, CAP, HEXAGON HEAD: COVER MTG MS90725-33 (96906)	EA	8						
02Z		COVER 10D30 (01942)	EA	1						
02Z		PLUG, EXPANSION F31 (01942)	EA	1						
02Z		BEARING, BRONZE F11 (01942)	EA	1						
02Z		O RING, COVER ANG227-235 (88044)	EA	1						

CODE	STOCK NUMBER	REF NUMBER & MFR CODE	USABLE ON CODE	UNIT OF MEAS	QTY INC IN UNIT	(10)	(11)	(12)	(13)	(14)
XAF22	5315-616-5522	GLAND F22 (01942)		EA	1					
PAF22		KEY, WOODRUFF MS35756-12 (96906)		EA	1	*	*	*	*	
XAF22		PINION 10015 (01942)		EA	1					
XAF22		SHAFT, PINION 10014 (01942)		EA	1					
XAF22		ROTOR 10026 (01942)		EA	1					
XBF22		RING, PACKING F18AT (01942)		EA	1					
XBF22		BEARING, BRONZE F11A (01942)		EA	1					
XAF22		RING, RETAINING 10058 (01942)		EA	1					
XAF22		NUT, LOCK; ADJUSTING SCREW E64 (01942)		EA	1					
XAF22		SCREW, ADJUSTING 10055 (01942)		EA	1					
XBF22		GASKET E68 (01942)		EA	1					
XAF22		BONNET 10057 (01942)		EA	1					
XAF22		O RING, VALVE AM6227-213 (88044)		EA	1					
XAF22		SPRING 10054 (01942)		EA	1					
XAF22		POPPET 10051 (01942)		EA	1					
XAF22		RING, RETAINING 10058 (01942)		EA	1					
XAF22		O RING, VALVE AM6227-213 (88044)		EA	1					
XAF22		CAGE, VALVE 10050 (01942)		EA	1					
XAF22		O RING AM6227-213 (88044)		EA	1					
XBO22	5305-269-3211	PLUG; CASING 10063 (01942)		EA	2					
XAF22		CASING; PUMP 100R4 (01942)		EA	1					
		GROUP 03 - PUMP AND GEARBOX BASE AND MOUNTING PLATE								
PAF22	5305-269-3211	SCREW, CAP, HEXAGON HEAD; PUMP AND GEARBOX BASE MTG MS90725-60 (96906)		EA	4	*	*	*	*	*
PAF22	5310-637-9541	LOCKWASHER; PUMP AND GEARBOX BASE MTG MS35338-46 (96906)		EA	4	*	*	*	*	*
XBF22	5310-761-6882	BASE, PUMP AND GEARBOX 13219E3378 (97403)		EA	1					
PAF22		NUT, HEXAGON; MTG PLATE MS51967-2 (96906)		EA	6	*	*	*	*	*

STOCK NUMBER	REF NUMBER & MFR CODE	USABLE ON CODE	UNIT OF MEAS	QTY INC IN UNIT	1-20	21-50	51-100	1-25	21-50	51-100
5310-582-5965	LOCKWASHER; MTG PLATE MS35338-44 (96906)		EA	6	*	*	*	*	*	*
	PLATE, MOUNTING; PUMP AND GEARBOX BASE 13219E3376 (97403)		EA	1						
5340-952-0064	SHOCK MOUNT, VIBRATION; MTG PLATE J4624-41 (76005)		EA	6	*	*	*	*	*	*
5305-964-0119	SCREW, TAPPING; THREAD CUTTING; INSTRUCTION PLATE MTG MS24629-10 (96906)		EA	4	*	*	*	*	*	*
	PLATE, INSTRUCTION; PUMP DISCHARGE VALVE 13219E3381 (97403)		EA	1	*	*	*	*	*	*
	SCREW, DRIVE; PLATE MTG AN535-6-4 (88044)		EA	4	*	*	*	*	*	*
	PLATE, TRANSPORTATION; HEATING KETTLE 1901222063 (15277)		EA	1						
	GROUP 04 - VALVES, FITTINGS, HOSE ASSEMBLIES, AND THERMOMETER									
4730-278-4774	ELBOW, UNION; 90 DEG, 1 IN. NPT 1282 (14959)		EA	1	*	*	*	*	*	*
	HOSE ASSEMBLY, FLEXIBLE 13219E3380 (96906)		EA	1	*	*	*	*	*	*
4730-187-7599	COUPLING, STRAIGHT; 1 IN. NPT WWP521 (81348)		EA	1	*	*	*	*	*	*
4730-288-7180	NIPPLE, PIPE; 1 IN. NPT, 8 IN. LG, STEEL WWN351 (81348)		EA	1	*	*	*	*	*	*
	NIPPLE, PIPE; 1 IN. NPT, 5 1/2 IN. LG, STEEL MS51953-131 (96906)		EA	1	*	*	*	*	*	*
	PLATE, FLOW INDICATOR; VALVE 1901222087 (15277)		EA	1						
	HANDLE, VALVE 605 (29215)		EA	1						
	RING, STOP; VALVE 1546C (29215)		EA	1						
	VALVE, 3-WAY; 1 IN. NPTF, 3 PORT FIG605-1 (29215)		EA	1	*	*	*	*	*	*
4730-196-2059	NIPPLE, CLOSE; 1 IN. NPT, STEEL MS51953-121 (96906)		EA	1	*	*	*	*	*	*
4730-221-5011	ELBOW, STREET; 90 DEG, 1 IN. NPT, STEEL MS51952-6 (96906)		EA	1	*	*	*	*	*	*
4730-196-1556	NIPPLE, PIPE; 1 IN. NPT, 5 IN. LG, STEEL WWN351 (81348)		EA	1	*	*	*	*	*	*
4730-189-2599	UNION, CLOSED; 1 IN. NPT, STEEL FIG463 (26403)		EA	1	*	*	*	*	*	*
	HOSE ASSEMBLY, FLEXIBLE FIG341-4 (41592)		EA	1	*	*	*	*	*	*
	VALVE, DRAIN; 1 1/2 IN. NPT 4 (70142)		EA	1	*	*	*	*	*	*
4730-277-8891	NIPPLE, PIPE; 1 1/2 IN. NPT, 3 IN. LG, STEEL MS51953-172 (96906)		EA	1	*	*	*	*	*	*

SWR CODE	FEDERAL STOCK NUMBER	REF NUMBER & MFR CODE	USABLE ON CODE	UNIT OF MEAS	QTY INC IN UNIT	DESCRIPTION					
						(a)	(b)	(c)	(d)	(e)	(f)
						1-20	21-50	51-100	1-20	21-50	51-100
XBOZZ		PLATE, FLOW INDICATOR: VALVE 1901222087 (15277)		EA	1						
XBOZZ		HANDLE, VALVE 605 (29215)		EA	1						
XBOZZ		RING, STOP: VALVE 1546C (29215)		EA	1						
PAOZZ		VALVE, 3-WAY: 1 1/2 IN. NPT, 3 PORT FIG605-1-1-2 (29215)		EA	1	*	*	*	*	*	*
PAOZZ	4730-054-2027	NIPPLE, PIPE: 1 1/2 IN. NPT, 9 IN. LG, STEEL MS51953-181 (96906)		EA	1	*	*	*	*	*	*
PAOZZ	6685-236-9089	THERMOMETER 30-63606HTS12 (38056)		EA	1	*	*	*	*	*	*
PAOZZ	4730-231-5654	REDUCER, PIPE: 1 IN. NPT X 3/4 IN. NPT, STEEL MS39232-9 (96906)		EA	1	*	*	*	*	*	*
PAOZZ		NIPPLE, PIPE: 1 IN. NPT, 8 IN. LG, STEEL MS51953-134 (96906)		EA	1	*	*	*	*	*	*
		GROUP 05 - HAND SPRAY ATTACHMENT AND FLEXIBLE HOSE									
PAOZZ		HOSE, FLEXIBLE: SPRAY BAR, 1 IN. ID, 15 FT LG FIG341-15 (41592)		EA	1	*	*	*	*	*	*
PAOOF		HAND SPRAY ATTACHMENT 19012CZ000 (15277)		EA	1	*	*	*	*	*	*
PAOZZ	4730-231-2412	CAP, PIPE: HAND SPRAY, 3/4 IN. STEEL WMP521 (81348)		EA	1	*	*	*	*	*	*
PAOZZ		NOZZLE, SPRAY: VEE-JET H3-BU50120 (82247)		EA	2	*	*	*	*	*	*
XBOZZ		SPRAY BAR WELDMENT 19012CB000 (15277)		EA	1						
PAOZZ		HANDLE ASSEMBLY: SPRAY BAR 19012CA000GP2 (15277)		EA	1	*	*	*	*	*	*
PAOZZ	5310-083-1251	NUT, HEXAGON: HANDLE ROD MTG SCREW MS51922-1 (96906)		EA	1	*	*	*	*	*	*
PAOZZ	5310-809-4058	WASHER, FLAT: HANDLE ROD MTG SCREW MS27183-10 (96906)		EA	1	*	*	*	*	*	*
XBOZZ		ROD, HANDLE 19012CA005 (15277)		EA	1						
PAOZZ	5310-809-4058	WASHER, FLAT: HANDLE ROD MTG SCREW MS27183-10 (96906)		EA	1	*	*	*	*	*	*
PAOZZ	5305-226-7234	SCREW, CAP, HEXAGON HEAD: HANDLE ROD MTG MS90725-26 (96906)		EA	1	*	*	*	*	*	*
XBOZZ		BRACKET, HANDLE 19012CA001-2 (15277)		EA	1						
PAOZZ		VALVE, BALL FIG700-5B3-4 (37239)		EA	1	*	*	*	*	*	*
PAOZZ	5310-761-6832	NUT, HEXAGON: HANDLE BRACKET MTG, U-BOLT MS51967-2 (96906)		EA	2	*	*	*	*	*	*
PAOZZ	5310-582-5965	WASHER, LOCK: HANDLE BRACKET MTG, U-BOLT		EA	2	*	*	*	*	*	*

(1) SWR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REF NUMBER & MFR CODE	(4) USABLE ON CODE	(5) UNIT OF MEAS	(6) QTY INC IN UNIT	(8) 30-DAY GS MAINT ALLOWANCE			(7) 30-DAY GS MAINT ALLOWANCE		
						(a)	(b)	(c)	(d)	(e)	(f)
						1-20	21-50	51-100	1-20	21-50	51-100
PA02Z		U-BOLT; HANDLE BRACKET MTG 1901ZC009 (15277)		EA	1	*	*	*	*	*	*
XBOZZ		PIPE, EXTENSION; SPRAY BAR 1901ZC002 (15277)		EA	1						
PA02Z		HANDLE ASSEMBLY; SPRAY BAR 1901ZCA006P1 (15277)		EA	1	*	*	*	*	*	*
PA02Z	5310-081-1251	NUT, HEXAGON; HANDLE ROD MTG SCREW MS51922-1 (96906)		EA	1	*	*	*	*	*	*
PA02Z	5310-809-4058	WASHER, FLAT; HANDLE ROD MTG SCREW MS27183-10 (96906)		EA	1	*	*	*	*	*	*
XBOZZ		ROD, HANDLE 1901ZCA005 (15277)		EA	1						
PA02Z	5310-809-4058	WASHER, FLAT; HANDLE ROD MTG SCREW MS27183-10 (96906)		EA	1	*	*	*	*	*	*
PA02Z	5305-226-7234	SCREW, CAP, HEXAGON HEAD; HANDLE ROD MTG MS90725-26 (96906)		EA	1	*	*	*	*	*	*
XBOZZ		BRACKET, HANDLE 1901ZCA001-1 (15277)		EA	1						
		GROUP 06 - FUEL TANK, PRESSURE GAGE, AIR PUMP, VALVES, LINES AND FITTINGS									
PA02Z		PET COCK; AIR BLEED DC601-2 (93061)		EA	1	*	*	*	*	*	*
XBOZZ		REDUCER, PIPE: PET COCK MTG, 1/2 IN. NPTF X 3/4 IN. NPTM 2090S1258 (93061)		EA	1						
PA02Z		CAP, PRESSURE RELEASE; FUEL TANK 1901ZE2000 (15277)		EA	1	*	*	*	*	*	*
PA02Z	4730-192-1472	NIPPLE, PIPE: CLOSED, 2 IN. NPT WMN351 (81348)		EA	1	*	*	*	*	*	*
PA02Z	4820-451-4654	VALVE, POP OFF; FUEL TANK, 55 PSI, 1/2 IN. NPT, BRASS 214598 (38056)		EA	1	*	*	*	*	*	*
PA02Z		GAGE, PRESSURE: FUEL TANK, 0 TO 60 PSI, 2 1/2 IN. DIAL 8197832 (73475)		EA	1	*	*	*	*	*	*
XBOZZ		NUT, LONG FLARE: TUBING, 1/4 IN. BRASS 41FS4 (93061)		EA	1						
XBOZZ		ADAPTER, PIPE: FLARED NUT 48F4-4 (93061)		EA	2						
XBOZZ		TEE, PIPE: PRESSURE GAGE 2203P4 (93061)		EA	1						
PA02Z		CONNECTOR, PIPE, STRAIGHT; PRESSURE GAGE MTG, 1/4 IN. TUBE X 1/4 IN. PIPE 48FS4-4 (93061)		EA	1	*	*	*	*	*	*
XBOZZ		NUT, LONG FLARE: TUBING, 1/4 IN. BRASS 41FS4 (93061)		EA	1						

(1) INR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REF NUMBER & MFR CODE	(4) USABLE ON CODE	(5) UNIT OF MEAS	(6) QTY INC IN UNIT	(7) 30-DAY GS MAINT ALLOWANCE			(8) 30-DAY GS MAINT ALLOWANCE		
						(a)	(b)	(c)	(a)	(b)	(c)
						1-20	21-50	51-100	1-20	21-50	51-
XS02Z		ADAPTER, PIPE: FLARED NUT 48F4-4 (93061)		EA	1						
PA02Z		CONNECTOR, PIPE, STRAIGHT: TUBE MTG, 1/4 IN. TUBE X 1/4 IN. PIPE 48F54-4 (93061)		EA	1	*	*	*	*	*	*
PA02Z	5310-422-2560	NUT, LONG FLARE: TUBING, 1/4 IN. BRASS 41FL4 (93061)		EA	2	*	*	*	*	*	*
PA02Z		TUBING, COPPER: FUEL TANK TO VALVE 1901ZZ2007-1 (15277)		EA	1	*	*	*	*	*	*
PA02Z		CONNECTOR, PIPE, STRAIGHT: TUBE TO VALVE, 1/4 IN. TUBE X 1/4 IN. PIPE 48F54-4 (93061)		EA	2	*	*	*	*	*	*
PA02Z		VALVE, GLOBE: FUEL TANK, 1/4 IN. NPT, BRASS 401-6 (15277)		EA	1	*	*	*	*	*	*
PA02Z	5310-422-2560	NUT, LONG FLARE: TUBING, 1/4 IN., BRASS 41FL4 (93061)		EA	2	*	*	*	*	*	*
PA02Z		TUBING, COPPER: VALVE TO TEMPERATURE CONTROL 1901ZZ2007-2 (15277)		EA	1	*	*	*	*	*	*
XB02Z		CONNECTOR, PIPE, STRAIGHT: TUBE TO TEMPERATURE CONTROL 48F54-4 (93061)		EA	1						
XB02Z		HOSE ASSEMBLY, TORCH: HAUCH MOL WHO34 14982X6 (27695)		EA	1						
XB02Z		BUSHING, PIPE: HOSE ASSEMBLY 209PS8-4 (93061)		EA	1						
XB02Z		NIPPLE, PIPE: HOSE ASSEMBLY 216P4 (93061)		EA	1						
XB02Z		ELBOW, PIPE: TEMPERATURE CONTROL 1202PS4-4 (93061)		EA	1						
XB02Z		BUSHING, PIPE: HOSE ASSEMBLY 209PS8-4 (93061)		EA	1						
XB02Z		NIPPLE, PIPE: HOSE ASSEMBLY 216P4 (93061)		EA	1						
XB02Z		ELBOW, PIPE: BURNER ASSEMBLY 202PS4-4 (93061)		EA	1						
PA02Z	4730-905-2692	COUPLING, PIPE: THERMOCOUPLE MTG MS39233-5 (96906)		EA	1	*	*	*	*	*	*
PA02Z	4730-288-6983	NIPPLE, PIPE: THERMOCOUPLE MTG MS51953-111 (96906)		EA	1	*	*	*	*	*	*
PA02Z	5310-982-4938	NUT, SQUARE: TEMPERATURE CONTROL ASSEMBLY MTG, 1/4-20 THD SIZE MS27040-10 (96906)		EA	2	*	*	*	*	*	*
PA02Z	5310-582-5965	LOCKWASHER: TEMPERATURE CONTROL ASSEMBLY MTG SCREW, 1/4 IN. MS35338-44 (96906)		EA	2	*	*	*	*	*	*
PA02Z	5305-988-1727	SCREW, PAN HEAD: TEMPERATURE CONTROL ASSEMBLY MTG, 1/4-20 UNC X 1 IN. LG		EA	2	*	*	*	*	*	*

NUMBER	REF NUMBER & MFR CODE	UNIT OF MEAS	INC IN UNIT	1-20	21-50	51-100	1-20	21-50	51-100	100 EQUIV CNT
ZZ 4320-451-2729	PUMP, AIR, HAND: FUEL TANK, 2 IN. SIZE 49 (70142)	EA	1	*	*	*	*	*	*	*
ZZ	PLATE, CAUTION: FUEL TANK 1901222088 (15277)	EA	1							
ZZ 5310-880-7744	NUT, HEXAGON: FUEL TANK MTG SCREW, 5/16-18 NC MS51967-5 (96906)	EA	4	*	*	*	*	*	*	*
ZZ 5310-407-9566	LOCKWASHER: FUEL TANK MTG SCREW, 5/16 IN. MS35338-45 (96906)	EA	4	*	*	*	*	*	*	*
Z 5310-225-8499	SCREW, CAP, HEXAGON HEAD: FUEL TANK MTG, 5/16-18 X 1 IN. LG MS90725-34 (96906)	EA	4	*	*	*	*	*	*	*
Z	TANK, FUEL, PRESSURIZED 1901FZZ000 (15277)	EA	1							
Z 4730-221-2137	PLUG, PIPE: FUEL TANK DRAIN, 1/4 IN. NPT MS20913-25 (96906)	EA	2	*	*	*	*	*	*	*
	GROUP 07 - TEMPERATURE CONTROL ASSEMBLY									
F 6685-405-1695	CONTROL ASSEMBLY, TEMPERATURE GWSSJ369AS8 (45809)	EA	1	*	*	*	*	*	*	*
Z	KNOB: TEMPERATURE CONTROL ZC26 (45809)	EA	1	*	*	*	*	*	*	*
Z 5305-984-6213	SCREW, CAP: COVER MTG MS35206-266 (96906)	EA	4	*	*	*	*	*	*	*
Z	COVER: TEMPERATURE CONTROL GWS10F (45809)	EA	1							
Z	GASKET, COVER: TEMPERATURE CONTROL GWS4 (45809)	EA	1	*	*	*	*	*	*	*
Z	SCREW, CAP, HEXAGON HEAD SLOTTED: FLANGE MTG L98 (45809)	EA	2							
Z	O RING: FLANGE ACC165 (45809)	EA	1							
Z	FLANGE, ELEMENT L4F (45809)	EA	1							
Z 6685-257-0188	ELEMENT, THERMOCOUPLE 445KLP110-5 (45809)	EA	1	*	*	*	*	*	*	*
Z	STUFFING BOX 3-4-21T105 (45809)	EA	1							
Z 5305-638-4027	SCREW, MACHINE: ROUNDHEAD, VALVE MTG 5800-30-31 (31741)	EA	4	*	*	*	*	*	*	*
Z 5310-045-3296	LOCKWASHER: VALVE MTG MS35338-43 (96906)	EA	4	*	*	*	*	*	*	*
	VALVE ASSEMBLY: TEMPERATURE CONTROL GWSSJ369S2 (45809)	EA	1							
	MECHANISM ASSEMBLY: TEMPERATURE CONTROL GWSSJ369S6 (45809)	EA	1							
Z 5305-059-4568	SCREW, MACHINE: FLATHEAD, RELIEF VALVE MTG MS35150-253 (96906)	EA	2	*	*	*	*	*	*	*

(1) SWR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REF NUMBER & MFR CODE	(4) USABLE ON CODE	(5) UNIT OF MEAS	(6) QTY INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE		
						(a)	(b)	(c)	(a)	(b)	(c)
						1-20	21-50	51-100	1-20	21-50	51-100
XBOZZ	5305-253-5612	VALVE ASSEMBLY, RELIEF GWSSJ36937 (45809)		EA	1						
XAOZZ		ADAPTER Y20B (45809)		EA	1						
PAOZZ		SCREW, DRIVE: PLATE MTG AN535-2-4 (88044)		EA	2	*	*	*	*	*	*
XBOZZ		PLATE, RATING: TEMPERATURE CONTROL 40-108 (45809)		EA	1						
XAOZZ		CASE: TEMPERATURE CONTROL GWSSJ369-11 (45809)		EA	1						
		GROUP 08 - BURNER ASSEMBLY									
XBOZZ		CONNECTOR, PIPE, STRAIGHT: BURNER VALVE, 1/4 IN NPT 2083-4-45 (02624)		EA	1						
XBOZZ		ELBOW, PIPE, STREET: 90 DEG, BURNER VALVE, 1/4 IN. NPTF, 1/4 IN. NPTM 1-4CDS (93061)		EA	1						
XBOZZ		HIPPLE, PIPE: BURNER VALVE, 1/4 IN. NPT 2084-457-8 (00624)		EA	1						
PAOFF		BURNER ASSEMBLY WHD34 (27695)		EA	1	*	*	*	*	*	*
XBOZZ		VALVE: BURNER WHD2 (27695)		EA	1						
XAFZZ		SHIELD, WIND WHD34-14 (27695)		EA	1						
XGFZZ		PLUG, VAPORIZING WHD34-9 (27695)		EA	1						
XAFZZ		HOLDER, PLUG WHD34-8 (27695)		EA	1						
PAOZZ		NOZZLE, BURNER WHD34-13 (27695)		EA	1	*	*	*	*	*	*
XBFZZ		COIL, BURNER WD34-11 (27695)		EA	1						
XAFZZ		PLATE, BACK WHD34-11 (27695)		EA	1						
XAFZZ		SHELL WHD34-12 (27695)		EA	1						
XAFZZ		PAN WHD34-10 (27695)		EA	1						
		GROUP 09 - INTERVEHICULAR CABLE, LIGHTS, REFLECTORS, AND WIRING HARNESS									
PAOZZ	2590-038-3914	CABLE ASSEMBLY, INTERVEHICULAR 7728811 (19207)		EA	1	*	*	*	*	*	*
PAOZZ	5310-761-6882	NUT, HEXAGON: RECEPTACLE AND COVER MTG SCREW MS51967-2 (96906)		EA	4	*	*	*	*	*	*
PAOZZ	5310-582-5965	LOCKWASHER: RECEPTACLE AND COVER MTG SCREW		EA	4	*	*	*	*	*	*

NUMBER	REF NUMBER & MFR CODE	USABLE ON CODE	UNIT OF MEAS	INC IN UNIT	1-20	21-50	51-100	1-20	21-50	51-100	100 EQUIP CNTCT	P TO EQU
05-225-3839	SCREW, CAP, HEXAGON HEAD: RECEPTACLE AND COVER MTG MS90725-8 (96906)		EA	4	*	*	*	*	*	*	*	
	RECEPTACLE: ELECTRICAL MS75021-1 (96906)		EA	1								
	COVER, RECEPTACLE: ELECTRICAL 7731428 (77820)		EA	1								
05-253-5622	SCREW, DRIVE: REFLECTOR MTG MS21318-41 (96906)		EA	4	*	*	*	*	*	*	*	
	REFLECTOR, RED MS35387-1 (96906)		EA	4								
	REFLECTOR, AMBER MS35387-2 (96906)		EA	4								
10-761-6882	NUT, HEXAGON: CLAMP MTG SCREW MS51967-2 (96906)		EA	2	*	*	*	*	*	*	*	
	CLAMP, CONDUIT 920 (82059)		EA	2								
05-988-1725	SCREW, MACHINE: CLAMP MTG MS35206-281 (96906)		EA	2	*	*	*	*	*	*	*	
	CONDUIT, STEEL: THIN WALL, 1/2 IN. DIA, 78 IN. LG 1-2ENT (89481)		IN	78								
	TUBING, PLASTIC: 1/2 IN. DIA, 72 IN. LG Z1T831 (81348)		IN	72								
0-934-9751	NUT, HEXAGON: LIGHT MTG SCREW MS35650-302 (96906)		EA	78	*	*	*	*	*	*	*	
0-045-3296	LOCKWASHER: LIGHT MTG SCREW MS35338-43 (96906)		EA	78	*	*	*	*	*	*	*	
05-616-4831	SCREW, MACHINE: LIGHT MTG MS35266-65 (96906)		EA	78	*	*	*	*	*	*	*	
0-727-3288	LIGHT, MARKER: RED, 24 VOLTS MS35424-2 (96906)		EA	4	*	*	*	*	*	*	*	
0-726-1916	LIGHT, MARKER: RED, 24 VOLTS MS35423-2 (96906)		EA	7	*	*	*	*	*	*	*	
0-019-0877	LAMP: BLACKOUT, STOP AND TURN SIGNAL MS15570-1251 (96906)		EA	2	*	*	*	*	*	*	*	
0-295-1184	LAMP: STOP AND TAILLIGHT 1034 (08806)		EA	1	*	*	*	*	*	*	*	
0-577-3434	LIGHT, MARKER: AMBER, 24 VOLTS MS35423-1 (96906)		EA	4	*	*	*	*	*	*	*	
0-577-3435	LIGHT, MARKER: AMBER, 24 VOLTS MS35424-1 (96906)		EA	4	*	*	*	*	*	*	*	
0-466-0310	LIGHT, STOP-TURN 0433 (81834)		EA	2	*	*	*	*	*	*	*	
0-337-6471	LIGHT, STOP-TURN MS1330-1 (96906)		EA	2	*	*	*	*	*	*	*	
	CONNECTOR ASSEMBLY MS27144-1 (96906)		EA	18								
	CONNECTOR ASSEMBLY MS27142-2 (96906)		EA	6								
5-925-6494	TERMINAL MS27148-1 (96906)		EA	2	*	*	*	*	*	*	*	
	BOARD, TERMINAL 601-4 (75382)		EA	2								





		REF NUMBER & MFR CODE	CODE	MEAS	UNIT	1-20	21-50	51-100	1-20	21-50	51
XB02Z		BOX, JUNCTION 1901M22007 (15277)	EA	1							
PA00F		HARNES, WIRING 1901MA2000 (15277)	EA	1	"	"	"	"	"	"	"
XB02Z		WIRE ASSEMBLY 1901MB2000-1 (15277)	EA	2							
XB02Z		WIRE ASSEMBLY 1901MB2000-2 (15277)	EA	2							
XB02Z		WIRE ASSEMBLY, GROUND 1901MC2000 (15277)	EA	2							
XB02Z		WIRE ASSEMBLY 1901MD2000-1 (15277)	EA	3							
XB02Z		WIRE ASSEMBLY 1901MD2000-2 (15277)	EA	1							
XB02Z		WIRE ASSEMBLY 1901MD2000-3 (15277)	EA	2							
XB02Z		WIRE ASSEMBLY 1901MD2000-4 (15277)	EA	2							
XB02Z		WIRE ASSEMBLY 1901MD2000-5 (15277)	EA	2							
XB02Z		WIRE ASSEMBLY 1901MD2000-6 (15277)	EA	1							
XB02Z		ADAPTER, CONNECTOR MS27147-1 (96906)	EA	15							
XB02Z		BREAKER, CIRCUIT 30056-305TH (13445)	EA	3							
		GROUP 10 - SPRING, HANGER ASSEMBLIES, SPRING AND AXLE CLAMP AND U-BOLT									
PAF2Z	5310-732-0560	NUT, HEXAGON: REAR BRACKET MTG SCREW MS51967-14 (96906)	EA	4	"	"	"	"	"	"	"
PAF2Z	5310-584-5272	LOCKWASHER: REAR BRACKET MTG SCREW MS35338-48 (96906)	EA	4	"	"	"	"	"	"	"
PAF2Z	5305-782-9495	SCREW, CAP, HEXAGON HEAD: REAR BRACKET MTG MS90725-111 (96906)	EA	4	"	"	"	"	"	"	"
PAF2Z	5310-732-0560	NUT, HEXAGON: FRONT BRACKET MTG SCREW MS51967-14 (96906)	EA	4	"	"	"	"	"	"	"
PAF2Z	5310-584-5272	LOCKWASHER: FRONT BRACKET MTG SCREW MS35338-48 (96906)	EA	4	"	"	"	"	"	"	"
PAF2Z	5305-782-9495	SCREW, CAP, HEXAGON HEAD: FRONT BRACKET MTG MS90725-111 (96906)	EA	4	"	"	"	"	"	"	"
PAF2Z		NUT: CLAMP MTG 4601-7 (22938)	EA	8	"	"	"	"	"	"	"
PAF2Z		U-BOLT: CLAMP MTG 5100-11 (22938)	EA	4	"	"	"	"	"	"	"
XB02Z		CLAMP, SPRING AND AXLE 5601-1 (22938)	EA	2							
XB02Z		HANGER ASSEMBLY: SPRING, FRONT 1-4250 (22938)	EA	2							


(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REF NUMBER & MFR CODE	(4) USABLE ON CODE UNIT OF MEAS	(5) QTY INC IN UNIT	(6) 30-DAY DS MAINT ALLOWANCE			(7) 30-DAY GS MAINT ALLOWANCE			E C
				(a)	(b)	(c)	(a)	(b)	(c)	
				1-20	21-50	51-100	1-20	21-50	51-100	
4730-172-0034	FITTING, LUBRICATION MS15003-6 (96906)	EA	2	*	*	*	*	*	*	
5315-839-5822	PIN, COTTER: SHACKLE BOLT MTG MS24665-353 (96906)	EA	2	*	*	*	*	*	*	
5310-850-6884	NUT, SHACKLE BOLT MS35692-45 (22938)	EA	2	*	*	*	*	*	*	
5306-136-9800	BOLT, SHACKLE: 9/16-18 UF X 3 7/8 IN. LG 5402-2 (22938)	EA	2	*	*	*	*	*	*	
	BRACKET: SPRING, FRONT 4250 (22938)	EA	2							
	HANGER ASSEMBLY: SPRING, REAR 1-4251 (22938)	EA	2							
5315-839-5822	PIN, COTTER: RIVET MTG, 1/8 X 1 IN. MS24665-353 (96906)	EA	2	*	*	*	*	*	*	
	RIVET: ROUNDHEAD, 9/16 IN. DIA X 3 IN. LG 5403-1 (22938)	EA	2							
	BRACKET: SPRING, REAR 4251 (22938)	EA	2							
	SPRING 1-4014 (22938)	EA	2	*	*	*	*	*	*	
	GROUP 11 - WHEEL, AXLE AND HUB ASSEMBLIES									
2610-678-1363	TIRE: 700 X 16 MS35388-33 (96906)	EA	2	*	*	*	*	*	*	
2610-269-7332	TUBE, TIRE: 700 X 16 MS35292-8 (96906)	EA	2	*	*	*	*	*	*	
5310-732-0560	NUT, STUD: WHEEL MTG, 1/2-20 THD SIZE MS51968-14 (96906)	EA	10	*	*	*	*	*	*	
5310-584-5272	LOCKWASHER: WHEEL MTG, 1/2 IN. MEDIUM PLAIN MS35338-48 (96906)	EA	10	*	*	*	*	*	*	
	WHEEL ASSEMBLY: 700 X 16 7387807 (00000)	EA	2							
	CAP, GREASE 6312 (22938)	EA	2							
	AXLE ASSEMBLY: WHEEL 1-2006 (22938)	EA	1	*	*	*	*	*	*	
315-285-7161	PIN, COTTER: SPINDLE NUT, 1/8 X 2 IN. MS24665-377 (96906)	EA	2	*	*	*	*	*	*	
	NUT, SPINDLE 4600-2 (22938)	EA	2	*	*	*	*	*	*	
530-455-1180	COLLAR, GREASE 6316 (22938)	EA	2	*	*	*	*	*	*	
	BEAM, AXLE 2006-21 (22938)	EA	1							


(1) SWR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REF NUMBER & MFR CODE	(4) USABLE ON CODE UNIT OF MEAS	(5) QTY INC IN UNIT	(6) 30-DAY GS MAINT ALLOWANCE			(7) 30-DAY GS MAINT ALLOWANCE		
					(a)	(b)	(c)	(a)	(b)	(c)
					1-20	21-50	51-100	1-20	21-50	51-100
PAOZZ	3110-224-9674	BEARING CONE, INNER 6057 (22938)	EA	2	*	*	*	*	*	*
PAOZZ		SEAL, GREASE 6311 (22938)	EA	2	*	*	*	*	*	*
PAOZZ	2530-455-1181	HUB ASSEMBLY, WHEEL 1-3612 (22938)	EA	2	*	*	*	*	*	*
XB0ZZ		HUB, STUD AND CUP ASSEMBLY 3603-1 (22938)	EA	2						
PAOZZ		BEARING CUP, OUTER 6151 (22938)	EA	2	*	*	*	*	*	*
PAOZZ		BEARING CUP, INNER 6152 (22938)	EA	2	*	*	*	*	*	*
PAOZZ		STUD, WHEEL 6251-3 (22938)	EA	10	*	*	*	*	*	*
XB0ZZ		HUB, WHEEL 3603 (22938)	EA	2						
		GROUP 12 - TANK, LID, SUPPORT JACKS AND FRAME								
XB0ZZ		RACK; KETTLE TANK 1901JZ000 (15277)	EA	1						
PAOZZ	5310-761-6882	NUT, HEXAGON; SEPARATOR PLATE MTG SCREW, 1/4-20 THD SIZE MS51967-2 (96906)	EA	3	*	*	*	*	*	*
PAOZZ	5310-582-5965	LOCKWASHER; SEPARATOR PLATE MTG SCREW, 1/4 IN. MS35338-44 (96906)	EA	3	*	*	*	*	*	*
PAOZZ	5305-225-3839	SCREW, CAP, HEXAGON HEAD; SEPARATOR PLATE MTG MS90725-8 (96906)	EA	3	*	*	*	*	*	*
XBOFZ		PLATE, SEPARATOR: NUMBER 1 1901ZZ022 (15277)	EA	1						
XBOFZ		PLATE, SEPARATOR: NUMBER 2 1901CZZ000 (15277)	EA	1						
MOOZZ		CHAIN ASSEMBLY, COVER: SAFETY 13219E3384 (97403) MANUFACTURE FROM:	EA	1						
PAOZZ	4010-585-2108	CHAIN, 33 IN. REQUIRED	EA		*	*	*	*	*	*
PAOZZ	4030-869-1529	HOOK, 2 EA	EA		*	*	*	*	*	*
PAOZZ		PIN, QUICK RELEASE: TANK LID LG45T625 (83014)	EA	1	*	*	*	*	*	*
PAOZZ		LANYARD ASSEMBLY: QUICK RELEASE PIN LW1036-6 (83014)	EA	1	*	*	*	*	*	*
PAOZZ	5310-761-6882	NUT, HEXAGON: TANK MTG SCREW, 1/4-20 THD SIZE MS51967-2 (96906)	EA	12	*	*	*	*	*	*
PAOZZ	5310-582-5965	LOCKWASHER; TANK MTG SCREW MS35338-44 (96906)	EA	12	*	*	*	*	*	*
PAOZZ	5305-225-3839	SCREW, CAP, HEXAGON HEAD; TANK MTG MS90725-8 (96906)	EA	12	*	*	*	*	*	*
PAOZZ	5310-761-6882	NUT, HEXAGON: SAFETY STUD, 1/4-20 THD SIZE	EA	2	*	*	*	*	*	*


FEDERAL STOCK NUMBER	DESCRIPTION	USABLE CN CODE	UNIT OF MEAS	QTY INC IN UNIT	30-DAY US MAINT ALLOWANCE			30-DAY US MAINT ALLOWANCE			1-YR ALW PER 100 EQUIP CNTGY
					(a)	(b)	(c)	(a)	(b)	(c)	
REF NUMBER & MFR CODE					1-20	21-50	51-100	1-20	21-50	51-100	
5310-582-5965	LOCKWASHER: SAFETY STUD, 1/4 IN. MS51967-2 (96906)		EA	1	*	*	*	*	*	*	*
	STUD: SAFETY, FUSIBLE SCREW, 1/4-20 THD SIZE, 1 1/2 IN. LG 1901EAC005 (15277)		EA	1	*	*	*	*	*	*	*
	LID, MELTING TANK 1901EAC000 (15277)		EA	1							
	TANK, WELDMENT 1901AZZ000 (15277)		EA	1							
5310-761-6882	NUT, HEXAGON: TANK VENT MTG SCREW, 1/4-20 THD SIZE MS51967-2 (96906)		EA	4	*	*	*	*	*	*	*
5310-582-5965	LOCKWASHER: TANK VENT MTG SCREW, 1/4 IN. MS35338-44 (96906)		EA	4	*	*	*	*	*	*	*
5305-225-3839	SCREW, CAP, HEXAGON HEAD: TANK VENT MTG MS90725-8 (96906)		EA	4	*	*	*	*	*	*	*
	VENT, TANK 1901GZZ000 (15277)		EA	1							
5310-761-6882	NUT, HEXAGON: BAFFLE MTG SCREW, 1/4-20 THD SIZE MS51967-2 (96906)		EA	12	*	*	*	*	*	*	*
5310-582-5965	LOCKWASHER: BAFFLE MTG SCREW MS35338-44 (96906)		EA	12	*	*	*	*	*	*	*
5305-225-3839	SCREW, CAP, HEXAGON HEAD: BAFFLE MTG MS90725-8 (96906)		EA	12	*	*	*	*	*	*	*
	BAFFLE, HEAT 1901ZZ2018 (15277)		EA	2							
	BAFFLE, HEAT 1901BZZ000-1 (15277)		EA	1							
	BAFFLE, HEAT 1901BZZ000-2 (15277)		EA	1							
	BAFFLE, HEAT 1901ZZ2048 (15277)		EA	1							
	CHOCK BLOCK ASSEMBLY TK16482 (03742)		EA	2	*	*	*	*	*	*	*
	PIN, QUICK RELEASE: JACK, CABLE ATTACHED, 1/4 IN. DIA X 4 9/16 IN. LG BLN4-4-562 (84256)		EA	4	*	*	*	*	*	*	*
	JACK, SUPPORT: REAR 1901DZZ000-1 (15277)		EA	1	*	*	*	*	*	*	*
	JACK, SUPPORT: FRONT 1901DZZ000-2 (15277)		EA	1	*	*	*	*	*	*	*
	CHAIN ASSEMBLY, SAFETY 0212-0425 (80535)		EA	2	*	*	*	*	*	*	*
	COLD SHUT N01-1-4 (13743)		EA	2	*	*	*	*	*	*	*
5305-253-5618	SCREW, DRIVE: PLATE MTG AN535-6-4 (88044)		EA	4	*	*	*	*	*	*	*
	PLATE, IDENTIFICATION 1901ZZ2062 (15277)		EA	1							


STOCK NUMBER	REF NUMBER & MFR CODE	USABLE ON CODE	UNIT OF MEAS	QTY INC IN UNIT	1-20	21-50	51-100	1-20	21-50	51-100	PER 100 EQUIP CNTG	AL PER 100 EQUIP
305-564-0119	SCREW, TAPPING, THREAD CUTTING: INSTRUCTION PLATE MTG MS24629-10 (56906)	EA	4	*	*	*	*	*	*	*	*	*
	PLATE, INSTRUCTION: TANK OUTLET VALVE 13219E33856 (97403)	EA	1	*	*	*	*	*	*	*	*	*
	FRAME, SHELL ASSEMBLY 1901E22000 (15277)	EA	1									






































Section VII. INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER
CROSS-REFERENCE TO FIGURE AND ITEM NUMBER

<u>FIG</u> <u>NO.</u>	<u>ITEM</u> <u>NO.</u>	<u>STOCK NUMBER</u>	<u>FIG</u> <u>NO.</u>
13	10	5310-637-9541	3
13	16		5
11	1	5310-732-0560	12
13	2		12
13	1		13
1	6	5310-761-6882	1
1	17		5
1	19		7
2	3		11
13	14		11
14			14
14			14
8			14
3	34		14
1	11		14
6	21	5310-809-4058	7
12	11		7
6	3		7
6	13		7
8	4	5310-850-6884	12
6	12	5310-880-7744	2
6	10		4
8	40		8
6	11	5310-934-9751	11
7	3	5310-982-4938	8
6	23	5315-285-7161	13
6	16	5315-616-5522	4
2	34	5315-839-5822	12
8	30		12
6	4	5365-477-0327	2
8	29	5935-925-6494	11
8	5	6220-337-6471	11
9	14	6220-466-0310	11
1	1	6220-577-3434	11
1	16	6220-577-3435	11
14	4	6220-726-1916	11
14	12	6220-727-3288	11
14	20	6240-019-0877	11
14	24	6240-295-1184	11
7	11	6685-236-9089	6
9	17	6685-405-1695	9
14	35		
11	7		
1	7		
5	1		
11	17		
9	10		
4	1		
12	3		
12	6		
5	8		
14	37		
9	2		
11	12		
8	33		
12	14		
9	11		
11	16		
7	19		
7	7		
8	38		
2	2		
4	4		
8	37		
8	15		
1	2		
1	4		
1	14		
5	5		
7	15		
8	32		
11	3		
14	3		
14	11		
14	14		
14	19		
14	22		

ACC165	45809	9	6	MS35338-46	96906	1
AM535-2-4	88044	9	17		96906	3
AM535-6-4	88044	5	10		96906	5
AN6227-213	88044	4	25	MS35338-48	96906	4
	88044	4	24		96906	12
AN6227-235	88044	4	11		96906	12
BLN4-1-562	84256	14	30		96906	13
DC601-2	93061	8	1	MS35387-1	96906	11
D433	81834	11	24	MS35387-2	96906	11
E64	01942	4	21	MS35388-93	96906	13
E68	01942	4	23	MS35423-1	96906	11
FIG341-15	41592	7	1	MS35423-2	96906	11
FIG341-4	41592	6	14	MS35424-1	96906	11
FIG463	26403	6	13	MS35424-2	96906	11
FIG605-1	29215	6	9	MS35650-302	96906	11
FIG605-1-1-2	29215	6	20	MS35756-12	96906	4
FIG700-503-4	37239	7	13	MS39230-1	96906	2
FR3	24617	3	7	MS39232-9	96906	6
F11	01942	4	10	MS39233-5	96906	8
F11A	01942	4	19	MS35692-45	22938	12
F18AT	01942	4	18	MS51330-1	96906	11
F22	01942	4	13	MS51922-1	96906	7
F31	01942	4	9		96906	7
GWS5J369-11	45809	9	19	MS51952-6	96906	6
GWS5J369A58	45809	9	12	MS51953-111	96906	8
GWS5J369S2	45809	9	13	MS51953-121	96906	6
GWS5J369S6	45809	9	15	MS51953-172	96906	6
GWS5J369S7	45809	9	3	MS51953-131	96906	6
GWS10F	45809	9	4	MS51953-134	96906	6
GWS4	45809	9	4	MS51953-181	96906	6
H3-8U50120	82247	7	11	MS51967-14	96906	12
H35E	24617	3	7		96906	12
J4624-41	76005	5	8		96906	13
LG4ST625	83014	14	9	MS51967-2	96906	1
LW1036-6	83014	14	9		96906	5
L4F	45809	9	7		96906	7
L98	45809	9	5		96906	11
MILH13444TYPE1	81348	1	11		96906	11
MS15003-6	96906	12	11		96906	14
MS15570-1251	96906	11	20		96906	14
MS20913-25	96906	8	40		96906	14
MS21318-41	96906	11	7		96906	14
MS24629-10	96906	5	8		96906	14
	96906	14	37	MS51967-5	96906	2
MS24665-353	96906	12	12		96906	4
	96906	12	17		96906	8
MS24665-377	96906	13	8	MS51968-14	96906	13
MS27040-10	96906	8	31	MS51968-8	96906	3
MS27142-2	96906	11	27	MS75021-1	96906	11
MS27144-1	96906	11	26	MS90725-111	96906	4
MS27147-1	96906	11	41		96906	12
MS27148-1	96906	11	28		96906	12
MS27183-10	96906	7	8		96906	7
	96906	7	10	MS90725-26	96906	4
	96906	7	20	MS90725-33	96906	8
	96906	7	22	MS90725-34	96906	2
MS27183-15	96906	3	3	MS90725-5	96906	4
MS35190-253	96906	9	14		96906	1
MS35206-266	96906	9	2	MS90725-6	96906	7
MS35206-281	96906	11	12	MS90725-60	96906	5
MS35206-283	96906	8	33		96906	1
MS35266-65	96906	11	17	MS90725-8	96906	11
MS35292-8	96906	13	2		96906	14
MS35338-43	96906	9	11		96906	14
	96906	11	16		96906	14
MS35338-44	96906	1	2		96906	14
	96906	1	4	MS90726-6	96906	1
	96906	5	5	NO1-1-4	13743	14
	96906	7	15	SC3-4	71176	1
	96906	8	32	TK164B2	03742	14
	96906	11	3	WD34-11	27695	10
	96906	14	3		27695	10
	96906	14	8	WHD2	27695	10
	96906	14	11	WHD34	27695	10
	96906	14	14	WHD34-10	27695	10
	96906	14	19	WHD34-12	27695	10
MS35338-45	96906	14	23	WHD34-13	27695	10
	96906	2	2	WHD34-14	27695	10
	96906	4	4	WHD34-8	27695	10
	96906	8	37	WHD34-9	27695	10
				WWH351	81348	6

	Mfg Code	Fia No.	Item No.	REFERENCE No.	Mfg CODE	Fia No.
	81348	6	12	1901222018	15277	14
	81348	8	4	1901222022	15277	14
	81348	7	3	1901222048	15277	14
	45809	9	1	1901222062	15277	14
	81348	11	14	1901222063	15277	5
	80535	14	33	1901222076	15277	7
	89481	11	13	1901222087	15277	6
	22938	13	7		15277	6
	22938	13	16	1901222088	15277	8
	93061	10	2	1901222136	15277	3
	22938	12	20	20TD31	21444	1
	22938	12	10	2006-21	22938	13
	22938	12	16	202PS4-4	93061	8
	97403	1	6	2083-4-45	00624	10
	01942	4	6	2084-457-8	00624	10
	01942	4	33	2090S1258	93061	8
	01942	4	16	209PS8-4	93061	8
	01942	4	15		93061	8
	01942	4	17	214598	38056	8
	01942	4	8	216F4	93061	8
	01942	4	30		93061	8
	01942	4	27	2203P4	93061	8
	01942	4	26	235031	24617	3
	01942	4	22	235302	24617	3
	01942	4	24	235303	24617	3
	01942	4	20	235306	24617	3
	01942	4	28	235307	24617	3
	01942	4	32	235309	24617	3
	08806	11	21	235311	24617	3
	45809	9	16	235312	24617	3
	93061	8	25	235313	24617	3
	14959	6	1	235323	24617	3
	97403	5	6	235325	24617	3
	97403	1	9	235326	24617	3
	97403	5	3	235332	24617	3
	97403	5	9	3-4-21T105	45809	9
	97403	14	7	30-63608HTS12	38056	6
	97403	14	38	30H182	01942	4
	27695	8	22	30056-30STK	13445	11
	24617	2	8	30182-2-4B	30780	1
	24617	2	33		30780	1
	29215	6	8		24617	3
	29215	6	19	35ME	22938	13
	15277	1	21	3603	22938	13
	15277	14	17	3603-1	70142	6
	15277	14	26	40-108	45809	9
	15277	14	27	400577	24617	3
	15277	14	6	400656	24617	3
	15277	14	31	401-6	15277	8
	15277	14	32	41FL4	93061	8
	15277	14	16		93061	8
	15277	14	15	41FS4	93061	8
	15277	14	39		93061	8
	15277	8	39		24617	2
	15277	14	21	411610-02C	24617	2
	15277	14	1	411620-21A	24617	2
	15277	11	31	411621-07B	24617	2
	15277	11	32	411621-08B	24617	2
	15277	11	33	411622-08H	24617	2
	15277	11	34	411622-08J	24617	2
	15277	11	35	411623-01R	24617	2
	15277	11	36	411625-10A	24617	2
	15277	11	37	411626-01B	24617	2
	15277	11	38	411626-01D	24617	2
	15277	11	39	411637-02C	24617	3
	15277	11	40	416546	24617	3
	15277	11	30	419009	38740	2
	15277	7	18		38740	3
	15277	7	6	4250	22938	12
	15277	7	24	4251	22938	12
	15277	7	12	426	00165	1
	15277	7	9	431005	24617	3
	15277	7	21	445KLP110-5	45809	9
	15277	7	5	4600-2	22938	13
	15277	7	2	4601-7	22938	12
	15277	7	17	467705	24617	2
	15277	7	16	4702-5	22938	13
	15277	1	5	48F54-4	93061	8
	15277	8	3		93061	8
	15277	8	16		93061	8
	15277	8	20	48F4-4	93061	8
	15277	8	12		93061	8

REFERENCE No.	MFG CODE	FID No.	ITEM No.
50254	24617	2	5
5100-11	22938	12	8
51309	24617	2	32
	24617	2	35
51744	24617	2	23
51828	24617	2	27
52152	24617	2	31
53852	24617	2	4
53908	24617	2	36
5402-2	22938	12	14
5403-1	22938	12	18
55592	24617	2	10
5601-1	22938	12	9
5800-30-31	31741	9	10
58092	24617	2	37
59529	24617	2	30
59863	24617	2	24
601-4	75382	11	29
602028-14A	24617	2	7
602082-35	24617	2	29
602083-16	24617	2	16
60288-01A	24617	2	19
605	29215	6	7
	29215	6	18
6057	22938	13	14
6058	22938	13	13
6151	22938	13	18
6152	22938	13	19
6251-3	22938	13	20
6311	22938	13	15
6312	22938	13	6
6316	22938	13	10
7387807	00000	13	5
7728811	19207	11	1
7731428	77820	11	6
79035-14A	24617	2	38
79070-02A	24617	2	6
804	00165	1	18
8197882	73475	8	6
86869-04A	24617	2	39
920	82059	11	11